

ABB solar inverters

Quick installation guide
UNO-DM-6.0-TL-PLUS-US-Q
(6.0 kW)

EN



APPLY HERE
THE WIRELESS
IDENTIFICATION LABEL

BCM.V2R09.0



Before starting installation, download the product manual from www.abb.com/solarinverters. Choose the correct country, string inverters, single phase, choose the product and proceed to the "download" section. Read and follow all safety and installation instructions to avoid disabling any safety features or making the warranty invalid.



1. Labels and Symbols

IMPORTANT SAFETY INSTRUCTIONS
SAVE THESE INSTRUCTIONS -- KEEP IN A SAFE PLACE!

The installer must read this document in its entirety before installing or commissioning this equipment. For more detailed information regarding proper installation and use of this product, refer to the product manual located at www.abb.com/solarinverters. The labels on the inverter have the markings, main technical data and identification of the equipment and manufacturer. The technical data shown in this quick installation guide does not replace that shown on the labels attached to the equipment.

Symbols used in the guide and on the products

	These are nationally recognized test laboratory marks showing certification to UL 1741 and CSA C22 No. 107.1		Phase
	Hazardous voltage		Direct and alternating currents, respectively
	General warning - Important safety information		Positive pole and negative pole of the input voltage (DC)
	Hot surfaces		Stored energy discharge time
	System earth conductor (main grounding protective earth, PE)		Consult product manual
	Equipment Grounding Conductor (EGC)		


- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2. Inverter Models and Components

This installation guide covers the inverter model UNO-DM-6.0-TL-PLUS-US-SB-RA-QU* (6 kW). Models equipped with Wireless communication, DC disconnection switch, Rapid Shutdown Power Supply and Arc Fault Detector. *The U suffix indicates the Unbalanced of the 2 Channels Current, always present in 6kW model (refer to datasheet or manual for further details)


Main components

02 LED panel	10 UNO-DM-PLUS Ethernet COM KIT or UNO-DM-COM KIT board (optional)	16 Protective Earth (PE) connection point	22 Lock screw position
04 Inverter front cover	11 Inverter	17 Conduit drill out sizes 3/4", 1" (drill out markings on back side)	23 Power supply for rapid shutdown (RSD) terminal blocks
05 Wiring box front cover	12 DC input terminal blocks (two MPPT)	18 lower flange	24 Locking Screw
06 DC disconnect switch	13 AC output terminal blocks	19 1/2" communication conduit drill out	
07 Wall bracket	14 Wiring box	20 Markings for 3/4" or 1" conduit drill outs	
09 Heatsink	15 Wi-Fi antenna (-B models only)	21 Opening for 3/4" AC conduit	




3. Installation site and position

- Refer Datasheet/Manual to confirm that the environmental specifications have been met
 - Do not install the inverter in full sun. If needed, use a sun shade to minimize solar irradiation, especially for temperatures over 104°F/40°C.
 - Do not install in closed spaces where air does not circulate freely
 - Always ensure that the flow of air around the inverter is not blocked, so as to prevent overheating.
 - Do not install the equipment near flammable substances (minimum distance: 10 ft).
 - Do not install the equipment on wooden walls or other flammable substances.
 - Do not install in inhabited rooms or where the prolonged presence of people or animals is expected, because of the inverter's noise level during operation. The sound level is heavily influenced by its location (for example, the surface around the inverter, the environment, etc.) and grid quality.
 - Install on a wall or strong structure capable of bearing weight
 - Install vertically with a maximum inclination as indicated in the figure
 - Maintain minimum clearance from objects blocking air circulation and spacing between inverter as indicated in the figures
 - Ensure sufficient working area in front of the inverter for wiring box access
 - If possible, install at eye level so that the LEDs can be seen easily
 - Install at a height that takes account of the weight of the equipment
 - Position multiple inverters side-by-side, maintaining minimum clearances (measured from the outermost edge of the inverter)
 - Multiple inverters can also be placed in a staggered arrangement. Minimum clearances for staggered arrangements include width of the inverter cover plus additional allowances for inverters arranged above or below
 - All installations over 6500' high (2,000 meters) must be assessed by ABB Technical Sales to determine the proper datasheet derating




4. Clamps terminal use

All power conductors will be inserted in spring clamp terminals. The figure shows an example of how to make the wire connection:
 1) Insert a small flat screwdriver in the slot and lightly press the screwdriver from top to bottom; insert the screwdriver until the spring opens.
 2) Insert the cable in the spring clamp.
 3) Remove the screwdriver.
 4) When connections are complete, give each wire a pull test



5. Rapid Shutdown


! If an RSD device is installed on the plant, the inverter will power-up only if both AC and DC are supplied!
 The installer must use an external rapid shutdown device compliant with the 2014 NEC. Automatic shutdown occurs at the rooftop box when utility power (AC) is lost or when the PV system's AC disconnect switch is opened. In jurisdictions requiring a dedicated activation switch, should be installed an emergency stop button external to the inverter. The wiring box has 24Vdc (0.4A max) on a spring-loaded terminal block designed to power-up an external RSD device. The wire size range of RSD terminals is 26-12 AWG.
 - Connect the RSD device respecting the polarity indicated on each RSD terminal.
 - Install RSD device wires in the RSD terminal block;
 +24V wire to +RSD terminal, - 24V wire to - RSD terminal



6. Input connection (DC)

! Confirm the correct polarity in the input strings. Confirm there is no ground leakage current in the PV array. When exposed to sunlight, the PV panels supply DC direct voltage to the inverter. The inverter's DC switch disconnects the DC current from the PV panels. In the "OFF" position the inverter will stop producing power, but DOES NOT disconnect the AC from the grid. To prevent electrocution hazards, all the connection operations must be carried out with the external AC disconnect switch, downstream of the inverter (grid side), open and locked out.
 The transformerless design requires that the PV array to be floating with respect to ground per NEC 690.35. DC PV string wire must be listed PV wire per NEC 690.35 rated minimum 600V. PV output conductors (wiring) must consist of sheathed (jacketed) multi-conductor cables or single insulated conductors (wires) which must be installed in an approved raceway. These conductors must be isolated from the enclosure and system grounding, as required by NEC 690.35. This is the responsibility of the installer.
 Confirm that the maximum PV array short circuit current for each DC input channel is within the inverter specification (see table in Section 14). Array equipment grounding must be installed per the requirements of the NEC and is the responsibility of the installer. A configuration program that can help to correctly size the photovoltaic system is available on at <http://www.stringsizer.abb.com>.
 - Turn the DC switch OFF
 - Loosen the four captive screws on the wiring box cover (Torx 20) and remove the cover
 - Pass the DC wires through the openings dedicated to the DC conduit.
! Conduit must be sealed using water-tight fittings to maintain NEMA Type 4X enclosure integrity. Installer should follow conduit manufacturers' guidelines and best practices.
 - Connect the DC wiring to DC input terminal blocks. DC wiring terminals are spring pressure type and accommodate a wire size range of 20-8 AWG. Connect the strings in either independent or parallel mode, following the appropriate set of instructions below:

Independent mode configuration	Parallel mode configuration
In case of two PV arrays, if each of them has a current rating lower than the maximum current rating for a single inverter channel, they may be connected as "IND" array, each with its own MPPT. In this case, do nothing with the jumper wires which came with the inverters. - Connect the positive side of the first PV array to +IN1, and its negative side to -IN1. - Connect the positive side of the second PV array to +IN2 and its negative side to -IN2. Up to four strings can be connected in independent mode. - During commissioning, confirm that the input mode is set to IND. If connecting a single array, configure the inverter for parallel input mode.	If a PV array's output current is more than the rating for a single inverter channel: - connect the red jumper wire between the +IN1 and +IN2 terminal block inputs. Then connect the jumper wire black wire between the -IN1 and -IN2 terminals. During commissioning remember to set the input mode to PAR. - Connect the array to the IN1 (MPPT1) and IN2 (MPPT2) input positions, running separate wires for positive (+) and negative (-) for each array.




3. Mounting instructions

Mount the inverter following the step-by-step procedure below.
! Do not remove the inverter chassis cover in adverse weather conditions (e.g. rain, snow) or during periods of high humidity (>95%).

Components included in mounting kit

Q.TY	
1	Wall bracket
2	T20 Wall bracket locking screw (to be used when lock springs are missing)
1	(Spare part) T20 screw for front cover
1 + 1	Jumpers for configuring paralleled inputs.
1	Quick installation guide (QIG)

- Position the bracket so that it is level on the wall or pole
 - It is the installer's responsibility to choose an appropriate number and distribution of attachment points. The choice must be based on the type of wall, frame or other support, the type of anchors to be used, and their ability to support 4 times the inverter's weight (4x33lbs=132lbs for all models).
 Depending on the type and number of attachment points, drill the required holes to mount the bracket (see figure detail A).
 - Secure the bracket to the wall or frame
 - If needed, make conduit cutouts in the wiring box chassis, before the wiring box is put on the wall
 - Carefully lift the inverter and hook it onto the bracket by inserting the two supports in the slots on the inverter (Figure B).
 - Proceed to anchor the inverter to the bracket by installing the two (one each side) locking screws (Figure C).
 If on the bracket are present the lateral lock springs, proceed to lock the inverter by pressing the lower part toward the wall or structure until the two springs on the bracket set the inverter in position (Figure C).
 - Secure the inverter chassis bottom flange to the mounting surface using another screw (see Figure detail C). Note that the bottom flange is not a load-bearing component.




To prevent electrocution hazards, open and lock out the external AC disconnect switch before connecting the AC conductors, and any time the AC wiring box cover is to be removed. Proper PPE is required. AC output overcurrent protection is not provided with the inverter; it is the responsibility of the end user to provide overcurrent protection for the AC output circuit.

- Run an approved raceway between the inverter and external AC disconnect switch.
- Pass the AC wires through the openings dedicated to the AC conduit.

When complete, seal conduit with water-tight fittings to maintain the NEMA type 4X enclosure rating. Installer should follow conduit manufacturers' guidelines and best practices.

Determine which AC output is applicable for the inverter model being installed. The AC wiring connections based on the AC grid type are shown in the table (also found on a label in the wiring box).

Table with columns: GRID STANDARD TYPE DE RESEAU, L1, L2, L3, 208V-3PH-Δ, 240V-SPLIT-PHASE, TERMINAL BORNE, WIRE CABLE.



Connect wiring to the numbered terminals based on selected grid type. AC wiring terminals are spring pressure type and accommodate a wire size range of 20-6 AWG.

Connect the protective earth (PE) cable to wiring box busbar. Screws the cable (max 4 wires 8AWG to 4AWG, copper) with 2.0Nm (1.5ft-lb) torque.

The default 240V split-phase connection requires the grid Neutral to be connected to the inverter for proper operation. Before connecting the inverter to the grid, the grid type must be selected during the commissioning phase.

When all connections are complete, reinstall the front covers and tighten the cover screws with 1.5Nm (13.2 in-lbs) torque.

LED and KEYS, in various combinations, may show the status conditions or perform complex actions to be explored by consulting the product manual.




Table titled 'LEDs' with columns: LED, Color, Description. Rows include POWER (Green), COMM STATUS (Multicolor), ALARM (Yellow), WLAN (Multicolor), and GFI (Red).

- STEP 3 - Date, Time and Time zone
- Set the Date, Time and Time zone (The inverter will propose these fields when available).
- When it's not possible for the inverter to detect the time protocol, these fields have to be manually entered.
- Click on "Next" button to proceed to the next stage of the configuration wizard.

Table for STEP 4 - Inverter country standard, Input mode, Meter and Energy policy. Columns: Country standard, Input mode, Meter.

From the moment that the grid standard is set, you have 24 hours to make any changes to the value, after which the "Country Select > Set Std." functionality is blocked, and the remaining time will have to be reset in order to have the 24 hours of operation available again in which to select a new grid standard.

Confirm the settings by clicking "DONE"; the inverter will reboot at the finish of the meter test phase (if installed). After the wizard is completed, the system will power-on. The inverter checks the grid voltage, measures the insulation resistance of the photovoltaic field with respect to ground and performs other auto-diagnostic checks.

To address any problems that may occur during the initial stages of operation of the system and to ensure the inverter remains fully functional, you are advised to check for any firmware updates in the download area of the website www.abb.com/solarinverters or at https://registration.abb.com/solarinverters.

From the moment that the grid standard is set, you have 24 hours to make any changes to the value, after which the "Country Select" functionality is blocked and the remaining time will have to be reset in order to have the 24 hours of operation available again.

Any inverters installed, or commissioned, in California after September 8, 2017 must be set to the Rule 21 country code USA - RULE21 @ 240 single [R21 240sp] or USA - RULE21 @ 208 single [R21 208s].

According to CEC requirements the UNO-DM-6.0-TL-PLUS-US-QU (no display model), display measured net generated energy and measured instantaneous power using a remote device like a smartphone, tablet or PC.

Abnormal grid conditions: The inverter is programmed to respond to abnormal grid conditions, as specified in the below table:

Table with columns: Condition, Voltage (V), Frequency (Hz), Max. time (sec) at 60Hz before cessation of current. Rows A through H.

Reconnection 300s (Default setting). Adjustable 20s to 1000s. 1. Vnom is the nominal output voltage rating. 2. Trip limit and trip time accuracy specification is as follows: Voltage: +/-2%, Frequency: +/-0.10Hz, Time: 2 grid cycles (33ms @ 60Hz). 3. Default settings aligned with IEEE 1547-2003 requirements.

To adjust voltage and frequency and disconnect times to meet local utility requirements, make modifications are made using the inverter embedded web user interface. The Token is required to unlock the "Admin Plus" functionalities (contact ABB solar inverter technical support 1-877-261-1374).

Table titled 'Fault currents and durations: During a grid fault including a short circuit condition, the inverter may inject current into the grid as specified below:'. Columns: Utility voltage (V), Fault current RMS (A), 1 cycle, 3 cycle, 5 cycle.

Output power derating at high ambient temperature: Under high ambient temperatures, the inverter is designed to automatically reduce its output power. Detailed derating curves by model are provided in the product manual found on www.abb.com/solarinverters.

Before proceeding with commissioning, make sure you have carried out all the operations and checks indicated in the previous sections of this quick installation guides, and verify that the inverter cover was properly closed!

Refer to the product manual for further information about the configuration and the use of the functionality of the internal Webserver. Consult the product manual for more information.

Commissioning and configuration of the inverter can be made using a wireless capable device such as a smartphone, tablet or laptop. The steps for commissioning are listed below:

- Set the inverter's DC disconnect switch and any external DC switches to "ON" position: If the input voltage applied to one of the two input channels is greater than the minimum starting voltage, the inverter will start up.
- The inverter is powered ONLY by the voltage coming from the photovoltaic generator: the presence of grid voltage alone IS NOT SUFFICIENT to allow the inverter to power up.
- If an RSD device is installed on the plant, the inverter will power-up only if both AC and DC are supplied!

Pre-commissioning phase 1 - Connection to the local Wi-Fi network
- DEVICE USED TABLET/SMARTPHONE.
Once powered, launch a QR reader for mobile and SCAN the QR code marked with 1 on the label on the right side of the inverter and connect to inverter network (tap connect).
The name of the Wi-Fi network created by the system, that the connection should be established with, will be: ABB-XX-XX-XX-XX-XX (where the X is the MAC address)
After this step wait 10 seconds to allow the WLAN connection



- DEVICE USED LAPTOP.
Enable the wireless on the device you are using for the commissioning and search for the network named ABB-XX-XX-XX-XX-XX-XX, where "X" is an hexadecimal number of the MAC Address (the MAC Address is indicated on the "wireless identification label" on the side of the inverter).
When prompted, type the PK (product key), including the dashes. Example: 1234-1234-1234-1234 as the network password.

Pre-commissioning phase 2 - Internal web UI access
- DEVICE USED TABLET/SMARTPHONE.
SCAN this QR code (it is also reported in the inverter pre-commissioning flyer inside the box of the inverter). An internet browser page showing the step by step procedure will be open.

The information contained in this QR code is the IP address of the web user interface of the inverter: http://192.168.117.1
Recommended browsers: Chrome from v.55, Firefox from v.50, Safari from V.10.2.1

- DEVICE USED LAPTOP.
Open an internet browser page and insert http://192.168.117.1 on the address bar.

STEP BY STEP COMMISSIONING WIZARD:

- STEP 1 - Administrator/User login credentials
- Set the Administrator account user and password (minimum 8 character for password): Administrator account can open and view the contents of photovoltaic site. Additionally, they can make changes to inverter settings. User and password are CASE SENSITIVE.
- Set the User account user and (optional) password (minimum 8 character for password): User account can only read data. It cannot make any changes. User and password are CASE SENSITIVE.
- Click on "Next" button to proceed to the next stage of the configuration wizard.

STEP 2 (Optional) - Residential wireless network connection.
The parameters relating to the home wireless network (set on the router) that must be step and set during this step are:

- IP Settings: DHCP or Static.
If you select the DHCP function (default setup) the router will automatically assign a dynamic IP address to the inverter whenever it tries to connect to the user network.
With Static, the user can assign a fixed IP address to the system. The data which has to be entered in order for IP static address assigning to take place will appear. Complete the additional fields at the bottom of the screen (all the fields are mandatory with the exception of the secondary DNS server).
- Available networks (SSID): Identify and select your own (home) wireless network from all those shown in the SSID field (you can carry out a new search of the networks that can be detected with the Update button). Once the network has been selected, confirm.
- Password: Wireless network password.
Enter the password for the destination network (if necessary) and start the connection attempt (it will take a few seconds).
- Click on "Connect" button to connect the inverter to the home wireless network.
- A message will ask for confirmation. Click "Next" to connect the inverter to the home wireless network.
- Once the inverter is connected to the domestic wireless network, a new message will confirm that.
The message provides the IP Address assigned by the home wireless network router to the inverter that can be used each time you want to access the internal webserver, with the inverter connected to the home wireless network. Take note of it.
- Click on "Next" button to proceed to the next stage of the configuration wizard.

The IP address assigned may vary for reasons connected to the wireless home router setup (for example, a very brief DHCP lease time). If verification of the address is required, it is usually possible to obtain the client list (and the corresponding IP addresses) from the wireless router administration panel.
If the inverter loses the connection with the home wireless network, it is available accessing the Wi-Fi network ABB-XX-XX-XX-XX-XX-XX, where "X" is an hexadecimal number of the MAC Address.

The most common causes of losing connectivity might be: different wireless network password, faulty or unreachable router, replacement of router (different SSID) without the necessary setting updates.

The Arc Fault Circuit Protection required by NFPA 70 Article 690.11 is provided by the inverter. The AFD performs a self-test when the system is started:

If the self-test results are OK, the inverter will continue to AC grid connection. If a potential problem on the AFD board is detected, the self test will result in error E053. During normal operation the input current is continually measured and analyzed. If a DC arc fault is detected during operation, the inverter disconnects from AC grid and generates an E050 error code (readable through internal Webserver). Based on the above conditions, the Leds behaviour is described in the table below:

Table with columns: Arc Fault pending, Self Test Failed, POWER, ALARM, GFI.

In order to reset the error, log into internal webserver and press on "reset AFD" button. This will clear the E050 error and restart the self test. If self-test results are OK, the inverter will reconnect to the AC grid; if the DC arc fault is still present, the inverter will result in error E050.

Refer to the product manual (downloadable on www.abb.com/solarinverters) for troubleshooting suggestions.

- The AFD self-test can be manually started anytime using the following procedure:
1. Turn off the inverter (switching off both DC and AC switches),
2. Turn on both the DC and AC switches and wait for self-test result.

If the AFD trips frequently, it means arcs are occurring. Turn the inverter OFF and request a complete check of the system wiring, including all connections and junction boxes, to locate the problem.

The inverter is equipped with advanced grid support functionality that is useful to support reactive loads and also assist in reliable operation of the utility grid in the presence of a large number of distributed energy generation sources. This section provides an overview of the available grid support functions. The parameters related to the grid support functions that are in this inverter can be modified by:

- Accessing the embedded Web User Interface.
- Accessing to settings under the Service menu requires a time-limited password, which can be obtained by calling ABB solar inverter technical support at 1-877-261-1374

1. Voltage ride-through
This inverter provides parameters to respond to undervoltage and overvoltage events. The inverter is designed to operate normally within the specified operating range. If voltage excursions occur, the inverter is designed to continue operating normally or cease to export power for a specified delay. Beyond this programmed delay, the inverter disconnects from the grid in the event of an abnormal voltage condition.

2. Frequency ride-through
This inverter provides parameters to respond to underfrequency and overfrequency events. If frequency excursions occur, the inverter is designed to continue operating normally for a specified delay. Beyond this programmed delay, the inverter disconnects from the grid in the event of an abnormal voltage condition.

3. Reactive power control
The inverter provides several modes of operation for reactive power control and are described below:
- Disable: This is the default setting. Under this setting, the inverter exports with a power factor of 1.0.
- Fixed power factor control (Cosφ set): In this mode, the operator can set the output power factor to a fixed value. When enabled, a new value will be set in the inverter.
- Q Fixed (Q Set): Sets the reactive power to a fixed value. When enabled, a new value will be set in the inverter.

- Power factor as function of output power (Watt/Cosφ Settings: Cosφ(P)): In this mode, the inverter reduces the power factor (cos-phi) as a function of the output power at a given operating point. The 4 points of the default curve, where you can set the % of Pmax values and related cos-phi, can be modified using the internal Webserver. When enabled, the curve will be set in the inverter.
- Dynamic Volt/VAR control (Volt/VAR Settings: Q(V)): Under this mode, the level of reactive power exported by the inverter is a function of the operating grid voltage, also known as a Volt/VAR curve. The 4 points of the default curve, where you can set the % of Vnom values and related % of Smax, can be modified using the internal Webserver. When enabled, the curve will be set in the inverter.

4. Active Power Control
This inverter offers several modes for active power reduction.
- Active Power Curtailment: Sets a new value of active power as % of Pmax. When enabled, a new value will be set in the inverter.
- CEI Average VGR Derating (only Italian grid standard): Sets, after a specific threshold, an active power derating based on the average of Vac on 10 minutes as per CEI-021 Italian grid standard.

- Volt/Watt settings: P(V). Under this mode, the level of active power exported by the inverter is a function of the operating grid voltage, also known as a Volt/Watt curve. The 4 points of the default curve, where you can set the % of Vnom values and related % of Pmax, can be modified using the internal Webserver. When enabled, the curve will be set in the inverter.
- Frequency/Watt function (Frequency Control: P(f)): In this mode, the inverter limits the active power as a function of the grid frequency.

5. Ramp control
The inverter is designed to control the rate at which output power is increased, either at startup, or after a temporary low power condition on the PV array (such as fast shading). The following ramp controls are provided on this inverter:
- Normal ramp: The normal ramp defines the maximum rate at which the inverter can increase the output power under normal operation. The normal ramp control limits the fluctuations in the output power in order to prevent instabilities on the utility grid.
- Soft start: The soft-start ramp defines the maximum rate at which the inverter can increase the output power when the inverter is first starting up. This startup may occur on a daily basis or when the inverter restarts after an abnormal grid event has ended.

Refer to the dedicated application note in the ABB Solar website for more details about the grid support functions.

