

ML-Series RBS
Remote Battery Switches

7713100 / 7717100

- Magnetic Latch (ML) - draws very low current in the ON or OFF states, and draws moderate current for very short time when changing state• Silver alloy contacts provide high reliability for switching live loads
- Manual override provides LOCK OFF capability for servicing and ON/OFF control with or without power
- LED output to remotely indicate switch state
- Tin-plated copper studs for maximum conductivity and corrosion resistance
- Label recesses for circuit identification
- includes a Remote Control Switch (2155)
- includes a Deutsch DTM connector (mating part not included but required)

Specifications	12V DC	24V DC
Wire Size and Current Rating	See table below	See table below
ML-Coil Function	Auto releasing	Auto releasing
Operating Current: Continuous	<13mA @ 25°C nominal voltage	<13mA @ 25°C nominal voltage
Changing Stage (20 ms)	<7A @ 25°C nominal voltage	<4A @ 25°C nominal voltage
Contact Circuit Voltage	16V DC Max.	32V DC Max.
Live Current Switching	300A @ 12V DC - 10,000 Cycles	150A @ 24V DC - 10,000 Cycles
Mechanical Endurance	100,000 Cycles	100,000 Cycles
Control Circuit Voltage	9-16V DC	18-32V DC
Terminal Stud Size	3/8"-16	3/8"-16
Maximum Terminal Stud Torque	140 in-lb (15.8 N•m)	140 in-lb (15.8 N•m)
Ring Terminal Size	3/8" (M10)	3/8" (M10)
Terminal Ring Diameter Clearance	1.18" (30 mm)	1.18" (30 mm)

Remote Control Contura Switch

Action	SPDT, ON-ON
Seals	Internal & External Gasket Panel Seal
Mounting Hole	0.83"x 1.45" (21.08 mm x 36.83 mm)
LED Rating	100,000 hours half-life
Harness Connector	Deutsch DTM Series DTM 06-6S
Mating Part Requirements	see LADD Industries at www.laddinc.com
Required Receptacle Shell	DTM-04-6P*
Wedgelock	WM-6P
Terminal Pins	1060-20-0122†
Sealing Plugs	0413-204-2005†
Hand Crimp Tooling	DTT-20-0‡

Regulatory Meets ISO 8846 and SAE J1171 external ignition protection requirements, CE marked, Rated IP66

* Special modifications are available depending on customer requirements. No polarization on standard product.

† Quantity depends on optional wire connections. The total number of pins and sealing plugs is 6.

‡ Required for hand assembly of wires and terminal pins.

Wire Size and Current Ratings

Wire Size	Cranking 30 sec.	Intermittent 5 min.	Continuous (UL 1107)
2/0 AWG (70 mm ²)	1,000A	400A	225A
4/0 AWG (120 mm ²)	1,100A	400A	300A
2x 4/0 AWG (2x 120 mm ²)	1,450A	700A	500A

PN	Termination	Control Circuit	Remote Control Switch Included
7713100	Deutsch Connector	12V DC	SPDT, ON-ON
7717100	Deutsch Connector	24V DC	SPDT, ON-ON

Blue Sea Systems, Inc.
4600 Ryzex Way
Bellingham, WA
98226 USA
Phone 360.738.8230
www.blueseacom





Overview of Application

The ML-Series Remote Battery Switch (ML-RBS) provides high-current carrying and switching under load. The ML-RBS should be installed close to the battery to minimize voltage drop to the ML-RBS.







Install a single pole double throw (SPDT) or single pole single throw (SPST) control switch in a convenient location near other electrical controls or companionway to allow quick access in the event of an emergency (see Illustration on reverse).*

* Although a SPST switch may be used if desired, use of a SPDT switch improves immunity to inadvertent switching if the switch terminals become damp.

Remote Operation

	Remote Switch Operation	ML-RBS Relay State	Remote Control Switch LED
ON	 To connect battery bank to load, or combine battery banks, press remote switch "ON".	 Remote Enabled ON (closed)	ON
OFF	 To disconnect battery bank from load, or isolate battery banks that are connected, press remote switch "OFF".	 Remote Enabled OFF (open)	OFF

Manual Override Operation

	ML-RBS Operation	ML-RBS Relay State	Remote Control Switch LED
	 To manually disconnect battery bank from load, or isolate battery banks that are connected, rotate manual override knob to the right.	 Manual Override LOCKED-OFF (open)	LED double blinking ON-OFF
	 To manually connect battery bank to load, or combine battery banks that are connected, rotate manual override knob to the left then push down until latched.	 Manual Override ON (closed)	LED double blinking ON-OFF
OFF	 To restore remote switching, manually set the RBS in the "Remote Enabled OFF (open)" position and push remote switch "OFF".	 Remote Enabled OFF (open)	LED OFF

⚠ CAUTION ⚠

- ✓ These instructions are intended to provide assistance with the installation of this product, and are not a substitute for a more comprehensive understanding of electrical systems. We strongly recommend that a competent electrical professional perform the installation of this product.
- ✓ The illustrated wiring diagram represents a common installation and is not meant to be a guide for wiring a specific vessel. The wiring diagram shows a single battery bank installation.
- ✓ Disconnect all negative battery connections before beginning the installation.
- ✓ All unused control wires should be carefully insulated from each other and from accidental contact using heat shrink tubing or electrical tape. External contact or shorting between control wires can lead to malfunction.

Installation Instructions

Mounting

Install as close as possible to battery bank. To avoid corrosion to connecting wires and terminals, mount in a dry and protected location. Avoid mounting directly above vented lead acid batteries so that the Remote Battery Switch is not exposed to corrosive gasses expelled from the batteries.

High Current Primary Circuit Connections (stud terminals A and B)

For help selecting the appropriate wire size and circuit protection rating, go to www.bluesea.com and click the *Circuit Wizard* quick link.

NOTE: Stud terminals A and B are interchangeable. A battery connection is required on one terminal for device operation

To connect high current circuit wires:

1. Connect the battery bank to one of the stud terminals marked A or B.
2. Connect the load to the other stud terminal marked B or A.
3. Torque the high current terminal stud nuts to 140 in-lbs (15.5 N•m) maximum.

NOTE: If switching an inverter, windlass, bow thruster, etc., the circuit wires must have circuit protection to comply with ABYC guidelines. Wires used for engine starting do not require circuit protection.


Control Circuit Connections (wires contained in the wire harness)

NOTE: The Remote Battery Switch is designed to be controlled by a SPDT or SPST switch.

Use minimum 16 AWG wire for the Control Circuits. For help selecting the appropriate wire size for the load cables, go to www.bluesea.com and click the *Circuit Wizard* quick link.

To connect the SPDT Remote Control Switch 2155:

1. Connect pin 3 and pin 8 to +12V or +24V Power available when Remote Battery Switch is OFF. (fused)
2. Connect the red control wire to switch pin 2.
3. Connect pin 7 to yellow wire.
4. Connect pin 1 to ground or negative.



Guarantee

Blue Sea Systems stands behind its products for as long as you own them.

Find detailed information at www.bluesea.com/about.

For customer service, call 800-222-7617.

Installation Instructions

