



**FORTRESS  
POWER**

# **Local and Remote Monitoring Set-Up Guide**

FP-Envy 8K/10K/12K



**TABLE OF CONTENTS**

**DONGLE INTEGRATION.....2**



**INVERTER AND END USER REGISTRATION (MOBILE METHOD) .....3**

**INVERTER AND END USER REGISTRATION [WEB PORTAL METHOD (SUGGESTED)] .....3**


**CONTACT INFORMATION.....6**

## Dongle Integration

1


1. Download the Envy Fortress Power APP Located both in Apple App Store  and Google Play Store  on a mobile device.

2




2. Plug the Dongle to the inverter while inverter is energized.
3. Connect to the Dongles Wi-Fi Network usually named **BA\*\*\*\*\***
4. Access the Envy App and Press the **WiFi Module Connect**.
5. Proceed to integrate the Dongle to the Home Wi-Fi by inputting the router's **SSID and Password**. **Server** must be Set to North America. After clicking on Set, Click **HomeWifi Connect**. The Dongle will display 3 solid LED's if the connection is successful. This may take 1 minute after selecting HomeWifi Connect.


3



4




5



If your cellphone does locate the customer's Router as shown on the 5<sup>th</sup> step image, then proceed to access the web browser on your cellphone or laptop while being connected to the dongle's Wi-Fi signal as seen in the 3<sup>rd</sup> step image. Type **10.10.10.1**>User: **admin**, Password: **admin**. Select **English** on the top right side. Next, Select **Station Mode Setting** and input the internet router's **SSID** and **Password**. Save and confirm that the Dongle has been integrated successfully by displaying 3 solid LEDs after 1 minute. **Warning. You must not access nor change any other values in this web portal. Doing so, may break the Dongle and make it inoperable.**

## Inverter and End user Registration (Mobile Method)

6. Select **Register** Tab
7. Complete End User Registration. Create End User username, password and make sure to select correct Continent, Region, Country, Time zone and physical Address. The Customer (Installer) Code shall be provided by Fortress Power to the Installer in which every installation done with this code will be reflected on the installer's portal. The serial number and pin of the dongle is located on the side of the dongle and the packaging box.
8. Once Registered, the user can access the End User Portal where they can view direction of power flow, Solar, Battery, Export, and Consumption Data.



## Inverter and End user Registration [Web Portal Method (Suggested)]

1. Follow the Dongle Integration Process
2. Search [envy.fortresspower.io](http://envy.fortresspower.io) and Login Installer Username and Password credentials. If any have not been assigned, please contact Tech Support.
3. Once Logged in, Go to **Configuration>Station>Add Station** (Create Plant Name). Please make sure you select the correct location and time zone.
4. After Creating Station, Go to **Dongles>Add Dongles>Input Dongle Serial Number and Pin** (located in the packaging box and right side of the Dongle) and associate the dongle to the **created station**.
5. Next, Go to **Users** and fill out the End-user profile and log in credentials.
6. Once User is added, Associate End-user by **User Management>Station Config> Select Station**
7. To give **Read Only** access to End-user, Select **User Management>Edit>Read Only**. Otherwise, leave **Normal**.

Monitor Data Configuration Overview Maintain Cluster: North America English Directenergy

Stations 2 + Add Station 3

| Station name | EndUser | Country | Timezone | Daylight saving time | Create date | Action |
|--------------|---------|---------|----------|----------------------|-------------|--------|
|--------------|---------|---------|----------|----------------------|-------------|--------|

Monitor Data Configuration Overview Maintain Cluster: North America English Directenergy

Stations

\* Station name  Create Plant Name

\* Create time

\* Continent

\* Region

\* Country

\* Timezone

\* Daylight saving time  Yes  No

Add Import Cancel

Monitor Data Configuration Overview Maintain Cluster: North America English Directenergy

Stations

+ Add Dongle 6 Import Dongle

| Serial number | Dongle type | Station name | EndUser | Create date | Connect Status | Last Update Time | Action     |
|---------------|-------------|--------------|---------|-------------|----------------|------------------|------------|
| 1             | B           |              |         |             |                |                  | Management |

New dongle

\* Dongle SN  Serial number 7

\* Dongle PIN  Dongle PIN

\* Station

Add Cancel

Monitor Data Configuration Overview Maintain Cluster: North America English Directenergy

Stations

Dongles

Devices

Users 8

\* Username  Username can not be empty

\* Password  Password can not be empty

\* Repeat password

Real name

\* E-mail

\* Continent

\* Region

\* Country

\* Timezone

\* Language

Tel number

Address

10 Add Back to user list

Monitor Data Configuration Overview Maintain Cluster: North America English Directenergy

Stations Dongles Devices Users

+ Add end user All Role Show disabled user Username Search by username

| Username | Real name | Role | E-mail | Country | Timezone | Tel number | Address | Create date | User Permissi | Customer code (Distributor Tech support type Tech support Cluster | Action          |
|----------|-----------|------|--------|---------|----------|------------|---------|-------------|---------------|---|-----------------|
| 1 Dir    |           |      |        |         |          |            |         |             |               |   | User Management |
| 2 BD     |           |      |        |         |          |            |         |             |               |   | User Management |
| 3 ma     |           |      |        |         |          |            |         |             |               |   | User Management |

11 Station Config Edit Modify password Remove Change target cluster

Monitor Data Configuration Overview Maintain Cluster: North America English Fortress

Stations Dongles Devices Users

Select station Puerto Rico 12 kw Office

13

Save Back to user list

Monitor Data Configuration Overview Maintain Cluster: North America English Directenergy

Stations Dongles Devices Users

+ Add end user All Role Show disabled user Username Search by username

| Username | Real name | Role | E-mail | Country | Timezone | Tel number | Address | Create date | User Permissi | Customer code (Distributor Tech support type Tech support Cluster | Action          |
|----------|-----------|------|--------|---------|----------|------------|---------|-------------|---------------|---|-----------------|
| 1 Dir    |           |      |        |         |          |            |         |             |               |   | User Management |
| 2 BD     |           |      |        |         |          |            |         |             |               |   | User Management |
| 3 ma     |           |      |        |         |          |            |         |             |               |   | User Management |

Station Config Edit Modify password Remove Change target cluster

Monitor Data Configuration Overview Maintain Cluster: North America English Directenergy

Stations Dongles Devices Users

\* Username [ ]

Installer [ ]

\* User Permission  Normal  Readonly 14

Real name Mateo Daniel

\* E-mail [ ] ✓

\* Continent North America

\* Region Caribbean

\* Country Puerto Rico

\* Timezone GMT -4

\* Language English

Tel number [ ]

Address [ ]

Update Back to user list



# FORTRESS POWER

**For Technical Support Please Contact us at  
Tech-Support Contact Information**

Useful Links

- Phone:  
Tech Support (877) 497-6937  
Tech Support (Spanish) (215) 710-8960
- Support Tickets: <https://www.fortresspower.com/support/>
- Warranty Submittal: <https://www.fortresspower.com/warranty/>