



User Manual

for S5 Series Grid Inverter



Applicable models

S5-GC75K-US

S5-GC80K-US

S5-GC90K-US

S5-GC100K-US

Important notes

- Product specifications are subject to change without notice. Every attempt has been made to make this document complete, accurate and up-to-date. Individuals reviewing this document and installers or service personnel are cautioned, however, that Solis reserves the right to make changes without notice and shall not be responsible for any damages, including indirect, incidental or consequential damages caused by reliance on the material presented including, but not limited to, omissions, typographical errors, arithmetical errors or listing errors in the material provided in this document.
- Solis accepts no liability for customers' failure to comply with the instructions for correct installation and will not be held responsible for upstream or downstream systems Solis equipment has supplied.
- The customer is fully liable for any modifications made to the system; therefore, any hardware or software modification, manipulation, or alteration not expressly approved by the manufacturer shall result in the immediate cancellation of the warranty.
- Given the countless possible system configurations and installation environments, it is essential to verify adherence to the following:
 - There is sufficient space suitable for housing the equipment.
 - Airborne noise produced depending on the environment.
 - Potential flammability hazards.
- Solis will not be held liable for defects or malfunctions arising from:
 - Improper use of the equipment.
 - Deterioration resulting from transportation or particular environmental conditions.
 - Performing maintenance incorrectly or not at all.
 - Tampering or unsafe repairs.
 - Use or installation by unqualified persons.
- This product contains lethal voltages and should be installed by qualified electrical or service personnel having experience with lethal voltages.

Table of Contents

1 Introduction

2 Safety

3 Installation

4 Communication

5 Commissioning

6 Settings

7 Maintenance

8 Troubleshooting

9 Specifications

10 Appendix

Table of Contents

| | |
|---|----|
| 1. Introduction | 4 |
| 1.1 Product Description | 4 |
| 1.2 Unpacking and storage | 5 |
| 1.2.1 Storage | 7 |
| 2. Safety Instruction | 8 |
| 2.1 Safety symbols | 8 |
| 2.2 General safety instructions | 8 |
| 2.3 Notice for use | 9 |
| 2.4 Protection Circuitry and Controls | 9 |
| 3. Installation | 10 |
| 3.1 Environmental considerations | 10 |
| 3.1.1 Select a location for the inverter | 10 |
| 3.1.2 Other environmental considerations | 12 |
| 3.2 Product handling | 13 |
| 3.3 Mounting the Inverter | 14 |
| 3.3.1 Wall mounting | 15 |
| 3.3.2 Rack mounting | 16 |
| 3.4 Electrical Connections | 19 |
| 3.4.1 Grounding | 20 |
| 3.4.2 Connect PV side of inverter | 22 |
| 3.4.3 Connect grid side of inverter | 24 |
| 4. Communication & Monitoring | 28 |
| 4.1 RS485 communication | 28 |
| 4.2 Ethernet communication | 31 |
| 5. Commissioning | 35 |
| 5.1 Selecting the appropriate grid standard | 35 |
| 5.1.1 Verifying grid standard for country of installation | 35 |
| 5.2 Changing the grid standard | 35 |
| 5.2.1 Procedure to set the grid standard | 35 |
| 5.3 Setting a custom grid standard | 36 |
| 5.4 Preliminary checks | 37 |
| 5.4.1 DC configuration | 37 |
| 5.4.2 AC configuration | 38 |
| 5.4.3 DC Connections | 38 |
| 5.4.4 AC Connections | 38 |
| 6. Normal operation | 39 |
| 6.1 Start-up procedure | 39 |
| 6.2 Shutdown procedure | 39 |
| 6.3 Main Menu | 40 |
| 6.4 Information | 40 |
| 6.4.1 Lock screen | 42 |

Table of Contents



| | |
|--|----|
| 6.5 Settings | 42 |
| 6.5.1 Set Time | 42 |
| 6.5.2 Set Address | 42 |
| 6.6 Advanced Info - Technicians Only | 43 |
| 6.6.1 Alarm Message | 43 |
| 6.6.2 Running Message | 43 |
| 6.6.3 Version | 44 |
| 6.6.4 Daily Energy | 44 |
| 6.6.5 Monthly Energy | 44 |
| 6.6.6 Yearly Energy | 45 |
| 6.6.7 Daily Records | 45 |
| 6.6.8 Communication Data | 45 |
| 6.6.9 Warning Message | 45 |
| 6.7 Advanced Settings - Technicians Only | 46 |
| 6.7.1 Selecting Standard | 46 |
| 6.7.2 Grid ON/OFF | 48 |
| 6.7.3 Clear Energy | 48 |
| 6.7.4 Reset Password | 48 |
| 6.7.5 Power control | 49 |
| 6.7.6 Calibrate Energy | 49 |
| 6.7.7 Special Settings | 49 |
| 6.7.8 STD Mode settings | 50 |
| 6.7.9 Restore Settings | 60 |
| 6.7.10 HMI Update | 61 |
| 6.7.11 External EPM Set | 61 |
| 6.7.12 Restart HMI | 61 |
| 6.7.13 Debug Parameter | 62 |
| 6.7.14 Fan Test | 62 |
| 6.7.15 DSP Update | 63 |
| 6.7.16 Compensation Set | 63 |
| 6.7.17 I/V Curve | 64 |
| 6.8 AFCI function | 65 |
| 7. Maintenance | 66 |
| 7.1 Anti-PID Function | 66 |
| 7.2 Fan Maintenance | 67 |
| 8. Troubleshooting | 68 |
| 8.1 Current Alarm | 68 |
| 8.2 Alarm History | 68 |
| 8.3 Error Messages | 68 |
| 9. Specifications | 72 |
| 10. Appendix | 76 |

1.1 Product Description

Solis Three phase Inverters convert DC power from the photovoltaic(PV) array into alternating current(AC) power that can satisfy local loads as well as feed the power distribution grid.

This manual covers the three phase inverter model listed below:


S5-GC75K-US, S5-GC80K-US, S5-GC90K-US, S5-GC100K-US



1.2 Unpacking and storage

The inverter ships with all accessories in one carton.


When unpacking, please verify all the parts listed below are included:



| Part # | Description | Number | Remarks |
|--------|-----------------|--|---------------------|
| 1 | Inverter | 1 | |
| 2 | Back plate | 1 | |
| 3 | Fastening screw | 2 | Hexagon bolt M6*12 |
| 4 | DC connector | 16 for 75K 18 for 80K 20 for (90-100)K | |
| 5-1 | Hexagon bolt | 4 | Hexagon bolt M10*40 |
| 5-2 | Hexagonal nut | 4 | |
| 5-3 | Washer | 4 | |
| 6 | User manual | 1 | |

Inverter packing list

1.3 Tools Required for Installation



1.2.1 Storage

If the inverter is not installed immediately, storage instructions and environmental conditions are listed below:

- Use the original box to repackage the inverter, seal with adhesive tape with the desiccant inside the box.
- Store the inverter in a clean and dry place, free of dust and dirt. The storage temperature must be between -40~158°F and humidity should be between 0 to 100%, non-condensing.
- Do not stack more than two (2) inverters high on a single pallet. Do not stack more than 2 pallets high.
- Keep the box(es) away from corrosive materials to avoid damage to the inverter enclosure.
- Inspect the packaging regularly. If packing is damaged (wet, pest damages, etc.), repackage the inverter immediately.
- Store inverters on a flat, hard surface -- not inclined or upside down.
- After 100 days of storage, the inverter and carton must be inspected for physical damage before installing. If stored for more than 1 year, the inverter needs to be fully examined and tested by qualified service or electrical personnel before using.
- Restarting after a long period of non-use requires the equipment be inspected and, in some cases, the removal of oxidation and dust that has settled inside the equipment will be required.



**DO NOT STACK
MORE THAN 2 HIGH**

SAVE THESE INSTRUCTIONS – This manual contains important instructions for Models S5-GC75K-US, S5-GC80K-US, S5-GC90K-US, S5-GC100K-US that shall be followed during installation and maintenance of the inverter.

2.1 Safety symbols

Safety symbols used in this manual, which highlight potential safety risks and important safety information, are listed below:



WARNING

Symbol indicates important safety instructions, which if not correctly followed, could result in serious injury or death.



NOTE

Symbol indicates important safety instructions, which if not correctly followed, could result in damage to or the destruction of the inverter.



CAUTION, RISK OF ELECTRIC SHOCK

Symbol indicates important safety instructions, which if not correctly followed, could result in electric shock



CAUTION, HOT SURFACE

Symbol indicates safety instructions, which if not correctly followed, could result in burns.

2.2 General safety instructions



WARNING

Do not connect PV array positive (+) or negative (-) to ground – doing so could cause serious damage to the inverter.



WARNING

Electrical installations must be done in accordance with local and national electrical safety standards.



WARNING

To reduce the risk of fire, branch circuit over-current protective devices (OCPD) are required for circuits connected to the Inverter.



CAUTION

The PV array (solar panels) supplies a DC voltage when exposed to light.



CAUTION

The inverter's surface temperature can reach up to 75°C (167°F). To avoid risk of burns, do not touch the surface when the inverter is operating. Inverter must be installed out of the reach of children.



WARNING

The inverter can only accept a PV array as a DC input. Using any other type of DC source could damage the inverter.



CAUTION

Risk of electric shock from energy stored in the inverter's capacitors. Do not remove cover until five (5) minutes after disconnecting all sources of supply have passed, and this can only be done by a service technician. The warranty may be voided if any unauthorized removal of cover occurs.

2.3 Notice for use

The inverter has been constructed according to applicable safety and technical guidelines. Use the inverter in installations that meet the following requirements ONLY:

- 1). The inverter must be permanently installed.
- 2). The electrical installation must meet all the applicable regulations and standards.
- 3). The inverter must be installed according to the instructions stated in this manual.
- 4). The system design must meet inverter specifications.

To start-up the inverter, the Grid Supply Main Switch (AC) must be turned on, BEFORE the DC Switch is turned on. To stop the inverter, see power down instruction on page 38 Section 6.2.

2.4 Protection Circuitry and Controls

To meet relevant codes and standards, the Solis U.S. three phase inverter line is equipped with protective circuitry and controls. These include Arc Fault Circuit Interrupter (AFCI) and Anti-Islanding Protection.

Arc Fault Circuit Interrupter AFCI:

Edition 2011 of the National Electrical Code®, Section 690.11, requires that all PV plants attached to a building are fitted with a means of detecting and interrupting serial electric arcs in the PV wiring and array. An electric arc with a power of 300W or greater must be interrupted by the AFCI in the time specified by UL 1699B. A triggered AFCI fault may only be reset manually. After clearing the source of the fault, the AFCI can be deactivated via the inverter front panel interface.

Anti-Islanding Protection:

Anti-Islanding is a condition where the inverter cease to produce power when the grid is not present. Circuitry, along with firmware, has been designed to determine if the grid is present by adjusting the output frequency of the inverter. In the case of a 60Hz resonant system where the inverter is partially isolated from the grid, the inverter programming can detect if there is a resonant condition or if the grid is actually present. It can also differentiate between inverter's operating in parallel and the grid.

3.1 Environmental considerations

3.1.1 Location selection for the inverter

When selecting a location for the inverter, consider the following:



WARNING: Risk of fire

Despite careful construction, electrical devices can cause fires.

- Do not install the inverter in areas containing highly flammable materials or gases.
- Do not install the inverter in potentially explosive atmospheres.



CAUTION, HOT SURFACE

- The temperature of the inverter heat-sink can reach 167°F.

- The ambient temperature and relative humidity should meet the following requirements.



Max.: +80°C
+140°F



Min.: -30°C
-22°F



Max. RH: 100%
(non-condensing)

- The load bearing structure shall meet the following requirements.



Made of non-flammable materials




Max. load bearing capacity ≥ 4
times of inverter weight



- If multiple inverters are installed on site, a minimum clearance of 30 inches should be kept between each inverter and all other mounted equipment. The bottom of the inverter should be at least 20 inches above of the ground or floor (see Figure 3.1 and 3.2).
- The LED status indicator lights and the LCD located on the inverter's front panel should not be blocked.
- Adequate ventilation must be present if the inverter is to be installed in a confined space.

3.1.1.1 Examples of correct and incorrect installations



3.1.2 Other environmental considerations

3.1.2.1 Consult technical data

Consult the specifications section (section 9) for additional environmental conditions (protection rating, temperature, humidity, altitude, etc.).

3.1.2.2 Horizontal installation

For horizontal installation, this model of Solis inverter should be mounted horizontally (upwards in more than 15 degrees off the horizontal plane).

3.1.2.3 Vertical wall installation

For vertical installation, this model of Solis inverter should be mounted vertically (90 degrees or backwards in less than or equal to 15 degrees).




Figure 3.1 Clearance distances requirement for the inverter




Figure 3.2 Distances required between inverters when multiple inverters are installed



NOTE
Nothing should be stored on or placed against the inverter.

3.1.2.4 Avoiding direct sunlight

Installation of the inverter in a location exposed to direct sunlight should to be avoided.

Direct exposure to sunlight could cause:

- Power output limitation (with a resulting decreased energy production by the system).
- Premature wear of the electrical/electromechanical components.
- Premature wear of the mechanical components (gaskets) and user interface.

3.1.2.5 Air circulation

Do not install in small, closed rooms where air cannot freely circulate. To prevent overheating, always ensure that the air flow around the inverter is not blocked.

3.1.2.6 Flammable substances

Do not install near flammable substances. Maintain a minimum distance of three (3) meters (10 feet) from such substances.

3.1.2.7 Living area

Do not install in a living area where the prolonged presence of people or animals is expected. Depending on where the inverter is installed (for example: the type of surface around the inverter, the general properties of the room, etc.) and the quality of the electricity supply, the sound level from the inverter can be quite high.

3.2 Product handling

Please review the instruction below for handling the inverter:

1. The red circles below denote cutouts on the product package.

Push in the cutouts to form handles for moving the inverter (see Figure 3.4).




Figure 3.4 Handles used to move the inverter shown circled in red

2. Two people are required to remove the inverter from the shipping box. Use the handles integrated into the heat sink to remove the inverter from the carton (see Figure 3.5).




Figure 3.5 Inverter handles



WARNING

Due to the weight of the inverter, contusions or bone fractures could occur when incorrectly lifting and mounting the inverter. When mounting the inverter, take the weight of the inverter into consideration. Use a suitable lifting technique when mounting.

3.3 Mounting the Inverter

The inverter can be mounted to the wall or metal array racking. The mounting holes should be consistent with the size of the bracket or the dimensions shown in Figure 3.6.




Figure 3.6 Inverter wall mounting

3.3.1 Wall mounting

Refer to figure 3.3, figure 3.7 and figure 3.8 Inverter shall be mounted upright, with electrical connections downward. The steps to mount the inverter are listed below.

1. Refer to Figure 3.7, drill holes for mounting screws based on the hole diameter of bracket using a precision drill keeping the drill perpendicular to the wall.
Max depth is 3.5 inch.
2. Make sure the bracket is horizontal. And the mounting holes (in Figure 3.7) are marked correctly. Drill the holes into wall at your marks.
3. Use the suitable mounting screws to attach the bracket on the wall.




Figure 3.7 Inverter wall mounting

4. Lift the inverter and hang it on the bracket, and then slide down to make sure they match perfectly.




Figure 3.8 Install the inverter

5. Use supplied 2 M6x12 hex bolts to secure the inverter to the bracket.




Figure 3.9 Secure the inverter

3.3.2 Rack mounting

The steps to mounted to the rack are listed below:

1. Select a location for the inverter

- With a TYPE NEMA 4X protection rating, the inverter can be installed both outdoors and indoors.
- When the inverter is running, the temperature of the chassis and heat sink will be higher than the ambient . Do not install the inverter in a location that you accidentally touch.
- Do not install the inverter in a place where it is stored near flammable or explosive material.

2. Installation angle

Install inverter as shown in Figure 3.10 below.

Install the inverter vertically. If the inverter cannot be mounted vertically, it may be

“mounted at angles greater than 15 degrees off horizontal. Inverter cannot be mounted flat.




Figure 3.10 Correct installation Angle




Figure 3.11 Wrong installation Angle

3. Install mounting plate

a. Remove the bracket and fasteners from the packaging. Mark the position for hole, drilling according to the hole positions of the bracket.




Figure 3.12 Mark the position for hole

b. Drill the marked holes. It is recommended to apply anti-corrosive paint at the hole for corrosion protection.




Figure 3.13 Drill hole

c. Align the mounting plate with the holes, Insert the combination bolt (M10X40) through the mounting plate into the hole. Secure the bracket to the metal frame firmly with the supplied fastener. Torque the nut to 25.8 ft.lbs.




Figure 3.14 Construction bolt

d. Lift the inverter above the bracket and then slide down to make sure they match perfectly.




Figure 3.15 Mount the inverter

e. Use supplied 2 M6x12 hex bolts to secure the inverter to the bracket (see figure 3.9).

3.4 Electrical Connections

Inverter design uses PV style quick-connect terminal. The top cover don't need be opened during DC electrical connection. The labels located on the bottom of the inverter are described below in table 3.1. All electrical connections must be in accordance with local or national standard.

| Parts | Connection | Cable size | Torque |
|-----------------------------|----------------------|---------------------------|----------------|
| DC terminal | PV strings | 12-8 AWG | NA |
| Ground terminal External | Equipment Ground | Local Code | 4.4-6.0 ft.lbs |
| Ground terminal Internal | AC ground | 2-4/0 AWG (Max 350MCM) | 17-21 ft.lbs |
| Grid terminal | Grid | 2-4/0 AWG (Max 350MCM) | 17-21 ft.lbs |
| RS-485 terminal | Communication cable | 22-12 AWG | 0.44 ft.lbs |
| RJ45 terminal | Communication cable | Network cable | NA |
| COM terminal | Wi-Fi/Cellular stick | NA | NA |

Table 3.1 Electrical connections

The electrical connection of the inverter must follow the steps listed below:

1. Switch the Grid Supply Main Switch (AC) OFF and LOTO the Main Switch.
2. Switch the DC Switch to OFF position.
3. Connect the inverter to the grid.
4. Assemble PV connector and connect to the Inverter.

3.4.1 Grounding

The inverter must be grounded for safety. Two methods are provided.

1. Connect the AC grounding cable. (See Section 3.4.3)
2. Connect the equipment grounding terminal on the heatsink described below.

To connect the grounding terminal on the heat sink, please follow the steps below:

1. It is recommended to use copper wire for the chassis ground. Either solid conductor or stranded wire is acceptable. Refer to local code standard for wire sizing.
2. Attach OT terminal: M10.



Important

For multiple inverters in parallel, all inverters should be connected to the same ground point to eliminate the possibility of a voltage potential existing between inverter grounds.

3. Strip the ground cable insulation to a suitable length. (see Figure 3.16)




Figure 3.16 Suitable length



Important

B (insulation stripping length) is 2mm-3mm longer than A (OT cable terminal crimping area).

4. Insert the stripped wire into the OT terminal crimping area and crimp with a hydraulic crimp tool. (see Figure 3.17)




Figure 3.17 Strip wire



Important

After crimping the terminal to the wire, inspect the connection to ensure the terminal is solidly crimped to the wire.

5. Remove the M10 screw from the heat sink ground point.

6. Connect the grounding cable to the grounding point on the heat sink, and tighten the grounding screw, Torque is 4.4-6.0 ft.lbs. (see figure 3.17)



Figure 3.17 Fixed cable



Important

For improving anti-corrosion performance, after ground cable installed, apply anti oxidizing grease.

3.4.2 Connect PV side of inverter



WARNING

Before connecting the inverter, make sure the PV array open circuit voltage is within the limit of the inverter. Otherwise, the inverter could be damaged.



WARNING

DO NOT connect the PV array positive or PV array negative cable to ground. This can cause serious damage to the inverter!



WARNING

MAKE SURE the polarity of the PV array output conductors matches the DC- and DC+ terminal labels before connecting these conductors to the terminals of the inverter.



WARNING

Please use the original DC MC4 terminals, otherwise the unqualified DC connectors may cause damages to the inverter.

Please see table 3.1 for acceptable wire size for DC connections. Wire must be copper only.

The steps to assemble the DC connectors are listed as follows:

1. Strip off the DC wire for about 7mm, Disassemble the connector cap nut.
2. Insert the wire into the connector cap nut and contact pin.




Figure 3.18 Disassemble the Connector Cap nut




Figure 3.19 Insert the Wire into the Connector Cap nut and contact pin

3. Crimp the contact pin to the wire using a proper wire crimper.
4. Insert metal connector into top of connector, and tighten nut with torque 3-4 Nm.




Figure 3.20 Crimp the contact pin to the wire



Figure 3.21 Connector with Cap nut Screwed on

5. Measure PV voltage of DC input with multimeter, verify DC input cable polarity (see figure 3.22), and ensure each string voltage is in range of inverter operation. Connect DC connector with inverter until hearing a slight clicking sound indicating successful connection. (see figure 3.23)




Figure 3.22 Multimeter measurement



Figure 3.23 Connect the DC Connectors to the Inverter



Caution

If DC inputs are accidentally reversely connected or inverter is faulty or not working properly, it is NOT allowed to turn off the DC switch. Otherwise it may cause DC arc and damage the inverter or even lead to a fire disaster.

The correct actions are:

*Use a clip-on ampmeter to measure the DC string current.

*If it is above 0.5A, please wait for the solar irradiance to drop until the current decreases to below 0.5A.

*Only after the current is below 0.5A, you are allowed to turn off the DC switches and disconnect the PV strings.

* In order to completely eliminate the possibility of failure, please disconnect the PV strings after turning off the DC switch to avoid secondary failures due to continuous PV energy on the next day.

Please note that any damages due to wrong operations are not covered in the device warranty.

Requirements for the PV modules per MPPT input:

- All PV modules must be of the same type and power rating.
- Please ensure the PV strings are evenly connected to the inverter and try to utilize all the MPPT trackers.
- All PV modules must be aligned and tilted identically.
- The open-circuit voltage of the PV array must never exceed the maximum input voltage of the inverter, even at the coldest expected temperature. (see section 9 “Specifications” for input current and voltage requirements)
- Each string connected to a single MPPT must consist of the same number of series-connected PV modules.
- Short circuit current of all strings connected to a single MPPT must not exceed the Max. Short Circuit rating of MPPT input. (see section 9 “Specifications” for Max. Short Circuit Current specification) .

3.4.2.1 DC connection high voltage danger notice



CAUTION
RISK OF ELECTRIC SHOCK

Do not touch an energized DC conductor. There is high voltages present when PV modules are exposed to light causing a risk of death due to an electric shock from touching a DC conductors!

Only connect the DC cables from the PV module to the inverter as described in this manual.



CAUTION
POTENTIAL DAMAGE TO THE INVERTER DUE TO OVERVOLTAGE

The DC input voltage of the PV modules must not exceed the maximum rating of the inverter. (see Section 9 "Specifications")

Check the polarity and the open-circuit voltage of the PV strings before connecting the DC cables to the inverter.

Confirm proper string length and voltage range before connecting DC cable to the inverter.

3.4.3 Connect grid side of inverter



WARNING
An over-current protection device must be used between the inverter and the grid.

1. Connect the three (3) AC conductors to the three (3) AC terminals marked "L1", "L2" and "L3". Refer to local code and voltage drop tables to determine the appropriate wire size and type.
2. Connect the grounding conductor to the terminal marked "PE" (protective earth, the ground terminal).



NOTE
The AC output neutral is not bounded to the ground.
The neutral wire is not necessary for the installation.

Over-Current Protection Device (OCPD) for the AC side

To protect the inverter's AC connection line, we recommend installing a device for protection against over-current and leakage, with the following characteristics noted in Table 3.2:



NOTE

Use AL-CU transfer (bi-metallic) terminal or anti-oxidant grease with aluminum cables and terminals.



NOTE

Inverter OCPD must be selected in accordance with National Electrical Code® ANSI/NFPA 70 or the Canadian Electrical Code® CSA C22.1. Operating ambient temperature and humidity must be factored and considered when selecting OCPD for the inverter output.

| Inverter | Rated voltage(V) | Rated output current (Amps) | Recommended current range for OCPD (A) |
|--------------|------------------|-----------------------------|--|
| S5-GC75K-US | 480 | 90.2 | 125 |
| S5-GC80K-US | 480 | 96.2 | 125-150 |
| S5-GC90K-US | 480 | 108.3 | 150 |
| S5-GC100K-US | 480 | 120.3 | 150-175 |

Table 3.2 Rating of grid OCPD

3.4.3.1 Connecting the inverter to the utility grid

All electrical installations must be carried out in accordance with the local standards and the National Electrical Code® ANSI/NFPA 70 or the Canadian Electrical Code® CSA C22.1. The AC and DC electric circuits are isolated from the enclosure. If required by section 250 of the National Electrical Code®, ANSI/NFPA 70, the installer is responsible for grounding the system.

The grid voltage must be within the permissible range. The exact operating range of the inverter is specified in Section 9 “Specifications”.

3.4.3.2 Wiring procedure



CAUTION

RISK OF ELECTRIC SHOCK. Prior to starting the wiring procedure, ensure that the three-pole circuit breaker is switched off and are LOTO.



NOTE

Damage or destruction of the inverter's electronic components due to moisture and dust intrusion will occur if the enclosure opening is enlarged.



CAUTION

Risk of fire if two conductors are connected to one terminal. If a connection of two conductors to a terminal is made, a fire can occur.
NEVER CONNECT MORE THAN ONE CONDUCTOR PER TERMINAL.



NOTE

Use M10 crimp terminals to connect to the inverter AC terminals.

The steps to assemble the AC grid terminals are listed as follows:

1. Strip the end of AC cable insulating jacket about 11.8 inch then strip the end of each wire. (See figure 3.25)




Figure 3.25 Strip AC cable



NOTE

S2 (insulation stripping length) is 2mm-3mm longer than S1.
(OT cable terminal crimping area)

2. Strip the insulation of the wire past the cable crimping area of the OT terminal, then use a hydraulic crimp tool to crimp the terminal. The crimped portion of the terminal must be insulated with heat shrinkable tube or insulating tape.



NOTE

If choosing aluminum alloy cable, you must use copper-aluminum transfer terminal or anti-oxidant grease in order to avoid oxidation of the connection from direct contact between aluminum and copper. (Please select a copper aluminum transfer terminal based on your cable specification).




Figure 3.26 AC Terminal Connection

3. LOTO the AC breaker disconnect to ensure it does not close unexpectedly.
4. Remove the 4 screws on the inverter junction box and remove the junction box cover. (See figure 3.27)




Figure 3.27 Remove the junction box cover

5. Insert the cable through the nut, sheath and AC terminal cover. If using conduit, remove plastic nut to expose hole for conduit connection. Connect the cable to the terminal block. Tighten the nuts on the terminal block to 17-21 ft-lbs. (See figure 3.28)





Figure 3.28 wiring

There are 5 communication terminals on Solis inverter. COM1 is a 4-pin connector reserved for Solis WiFi/Cellular datalogger. COM2 and COM3 are RS485 connection between inverters and both RJ45 and Terminal block are provided for use . COM4 and COM5 are the Ethernet connection via RJ45.

Monitoring system for multiple inverters

Multiple inverters can be monitored through RS-485 and Ethernet daisy chain configuration.




4.1 RS485 communication

RS-485 communication supports two connections methods: RJ45 connectors/ Terminal board

1. RS-485 communication through RJ45 connector

RJ45 port connection (See figure 4.2).

CAT 5E outdoor rated (cable outer diameter<9mm, internal resistance $\leq 1.5 \Omega / 10m$) and shielded RJ45 connectors are recommended.



Communication Board




Figure 4.3 Communication Board Detail

| Location | Reference Designation | Description |
|----------|-----------------------|--|
| 1 | J8 | RS485 from the LCD board to the Ethernet module |
| 2 | J3 | RS485 from main COM board to the Ethernet module |
| 3 | J2 | Ethernet Port (Output) |
| 4 | J5 | RS485 Ports (Rj45 Output) |
| 5 | P4P9 | RS485 Port (Terminal Output) |
| 6 | P3P8 | RS485 Port (Terminal Output) |
| 7 | P2 | Meter RS485 from the LCD board |
| 8 | P13 | Meter RS485 (Output) |
| 9 | J3 | DRM from The LCD board |
| 10 | J4 | DRM (Output) |
| 11 | P1 | RS485 from the LCD board |
| 12 | P5 | RS485 to the 4pin COM port |

Use the network wire stripper to strip the insulation layer off the communication cable.
Using the standard wire sequence referenced in TIA/EIA 568B, separate the wires in the cable.
Use a network cable tool to trim the wire. Flatten the wire in the order shown in figure 4.4.

Correspondence between the cables and the stitches of plug

Pin 1: white and orange ; Pin 2: orange
Pin 3: white and green; Pin 4: blue
Pin 5: white and blue; Pin 6: green
Pin 7: white and brown; Pin 8: brown

Pin 1 with 4 and 2 with 5 are used for communication connection

Pin 1 and 4 are connected with RS485+A
Pin 2 and 5 are connected with RS485 - B

Figure 4.4 Strip the insulation layer and connect to RJ45 plug

2. RS-485 communication through terminal board.

The cross sectional area of the conductor wire for terminal board connection should be 0.2-1.5mm.

The outer diameter of the cable may be 5mm-10mm.



| NO. | Port definition | Description |
|-----|-----------------|------------------------------------|
| 1 | RS485A1 IN | RS485A1,RS485 differential signal+ |
| 2 | RS485B1 IN | RS485B1,RS485 differential signal- |
| 3 | RS485A2 OUT | RS485A2,RS485 differential signal+ |
| 4 | RS485B2 OUT | RS485B2,RS485 differential signal- |

Figure 4.5

Connection of Terminal board.

a. Strip the insulation and shield to a suitable length. Use diagram below as a guide.
(See figure 4.5).

b. Remove the cap nut from the waterproof cable glands labeled at the bottom of the inverter.
Remove the plug from the fitting. (See figure 4.7).



- c. Insert the cable through the cap nut for each port.COM2(RS485 IN) COM3(RS485 OUT).
- d. Remove the terminal block on user interface board(See Figure 4.5).
- e. Insert the cable into the terminal board and tighten the screws in dotted area(See Figure 4.5).
- f. Replace terminal block onto interface board.


4.2 Ethernet communication

Use the RJ45 connectors to perform the Ethernet communication which supports the Solis Monitoring Platform and Modbus TCP protocol(Both By Default).



NOTE
When creating daisy chain for Ethernet communication, **all inverters' slave address must be set to 01.**

CAT 5E outdoor rated (cable outer diameter<9mm, internal resistance≤1.5Ω/10m) and shielded RJ45 connectors are recommended.
The default setting of inverter Ethernet module is DHCP. If a static address is desired, please refer to the second point below.
Daisy chain is required for multiple inverter communication through ethernet as shown below.



NOTE
Laptop is required for onsite Ethernet communication commissioning.
If the router doesn't support automatic IP address, use an Ethernet cable to connect the Ethernet module and your laptop.
Change the Laptop's IP address as 10.10.100.253 and then use a web browser to navigate to 10.10.100.254.

| System | Device information | |
|-----------|--------------------------|-----------------------------------|
| Work mode | Type | Embedded Ethernet |
| Network | SN | 1909583738 |
| Manual | Firmware version | ME-121001-V1.0.6(20200612800) |
| Restart | Current tiom (Time zone) | Fri Nov 06 2020 16:14:31 GMT+0800 |
| Reset | Working time | 116 Second |
| Upgrade | Error | 0 |

Figure 4.9



NOTE Laptop IP Configuration

The laptop must be manually configured to set internal IP address to one in scope of the LAN module in the inverter.
The process will vary depending on your operating system.
Consult the documentation for your operating system to configure a static IP address for the laptop. Suggested IP address is 10.10.100.253.

1. Monitoring Platform Solis monitoring only(DHCP)

Connect in daisy chain configuration see Figure 4.8. Use the SN/QR code on the board to register the system on Solis monitoring website or APP. See APP for details.



Figure 4.10

2. Monitoring Platform Solis monitoring only(Static IP)

1. Connect laptop directly to Ethernet module with Ethernet cable.
2. Configure laptop IP address and navigate to 10.10.100.254 via web browser.
Enter username and password (admin,admin).
3. Select Network from left menu.
4. Select Use IP address below radio button.
Enter IP address, subnet mask and default gateway. Click Save.
5. Confirm by changing laptop to new IP address in range of inverter IP address and navigate to new inverter IP address.

3. Modbus TCP with DHCP

- 1. Connect laptop directly to Ethernet module with Ethernet cable.
- 2. Configure laptop IP address and navigate to 10.10.100.254 via web browser.
Enter username and password (admin,admin).
- 3. Select Work mode in left menu. Change Work mode to "Local" and Protocol type to "Modbus TCP".
- 4. Connect inverters in daisy chain configuration see Figure 4.8. An IP address will be assigned by the DHCP server. Refer to router configuration pages to find assigned IP address.

| | | |
|-----------|---------------------------|----------------|
| System | Work mode settings | |
| Work mode | Work mode | Local + Remote |
| Network | Protocol type | ModBus TCP |
| Manual | IP address of the device | 192.168.3.50 |
| Restart | Port of the device | 30003 |
| Reset | | |
| Upgrade | Save | |

Figure 4.11

4. Modbus TCP with static IP

- 1. Connect laptop directly to Ethernet module with Ethernet cable.
- 2. Configure laptop IP address and navigate to 10.10.100.254 via web browser.
Enter username and password (admin,admin).
- 3. Select Work mode in left menu. Change Work mode to "Local" and Protocol type to "Modbus TCP".
- 5. Select Use IP address below radio button.
Enter IP address, subnet mask and default gateway. Click Save.
- 6. Confirm by changing laptop to new IP address in range of inverter IP address and navigate to new inverter IP address.

| | | |
|-----------|--|----------------|
| System | <input type="radio"/> Obtain IP address automatically | |
| Work mode | <input checked="" type="radio"/> Use the IP address below | |
| Network | IP address | 192.168.3.76 |
| Manual | Subnet mask | 255.255.255.0 |
| Restart | Default gateway | 192.168.3.1 |
| Reset | <input type="radio"/> Obtain DNS address automatically | |
| Upgrade | <input checked="" type="radio"/> Use the DNS address below | |
| | Preferred DNS server | 208.67.222.222 |
| | Optional DNS server | 208.67.222.222 |
| | Save | |

Figure 4.12

5. Ethernet Module LED Indicators

D1 Red LED: Indicator between module and inverter.

Constantly ON indicates normal connection.

Blinking indicates it is trying to connect.

OFF indicates connection failed.

Constantly ON but blinking sometimes indicates it is transferring data between inverter.

D2 Red LED: Indicator between module and server.

Constantly ON indicates normal connection.

Blinking indicates it is trying to connect.

OFF indicates connection failed.

Constantly ON but blinking sometimes indicates it is transferring data between the server.

D3 Green LED: Module power light.

Constantly ON indicates power supply normal.

OFF indicates power supply abnormal.

D1 and D2 slowly blinking alternately or slowly blinking synchronously indicates abnormal network issue.

D1 and D2 both OFF with D3 ON indicates the module is initializing.




Figure 4.13

5.1 Selecting the appropriate grid standard

5.1.1 Verifying grid standard for country of installation

Solis inverters are used worldwide and feature preset standards for operating on any grid. Although the grid standard is set at the factory, it is essential the grid standard be verified for the country of installation before commissioning.

The menu for changing the grid standard or for creating a custom standard is accessible as described in Section 6.7 and below.



WARNING

Failure to set the correct grid standard could result in improper operation of the inverter, inverter damage or the inverter not operating at all.

5.2 Changing the grid standard

5.2.1 Procedure to set the grid standard



NOTE


This operation is for service technicians only. The inverter is customized according to the local grid standard before shipping. There should be no requirement to set the standard.



NOTE

The “User-Def” function can only be used by the service engineer. Changing the protection level must be approved by the local utility.


1. From the main screen on the display, select **ENTER**. There are 4 sub-menu options, use the UP/DOWN arrows to highlight **ADVANCED SETTINGS**. Press enter to select.



Information
Settings

Figure 5.1

2. The screen will show that a password is required. The default password is "0010", press the DOWN key to move cursor, press the UP key to change the highlighted digit.



YES=<ENT> NO=<ESC>
Password:0000

Figure 5.2

3. Use the UP/DOWN keys to highlight the **SELECT STANDARD** option. Press enter to select.




Figure 5.3

4. Select the grid standard for the country of installation.




Figure 5.4

Press the UP or DOWN key to select the standard. Press the **ENTER** key to confirm the setting. Press the **ESC** key to cancel changes and return to the previous menu.

UL-480V-18, R21P3-480, ISONE480 are available for U.S.

5.3 Setting a custom grid standard

WARNING



- Failure to set the correct grid standard could result in improper operation of the inverter, inverter damage or the inverter not operating at all.
- Only certified personnel should set the grid standard.
- Only set the grid configuration that is approved by your location and national grid standards.

1. Please refer to section 6.7 “Advanced Settings” for procedures to create a custom grid configuration for User-Def menu option.

5.4 Preliminary checks



WARNING

High Voltage.

AC and DC measurements should be made only by qualified personnel.

5.4.1 DC configuration

Verify DC configuration by noting the number of panels in a string and the string voltage.

5.4.1.1 VOC and Polarity

Measure VOC, and check string polarity. Ensure both are correct and VOC is within specification.

5.4.1.1.1 Check string voltage

To measure the open circuit voltage (VOC) and polarity of the individual strings, perform the following steps:

1. Connect the positive lead of the meter to the positive string cable of the string under test.
Connect the negative lead of the meter to the negative string cable of the string under test.
2. Measure the voltage present between the positive and negative wires of each string.
If the open circuit voltage of the string is near the maximum value accepted by the inverter, verify the string length. Low ambient temperatures cause an increase in the string voltage causing potential damage to the inverter.
3. Check the polarity of the string. All digital meters have a negative ("-") indicator that indicates when a voltage is negative; in this case a string connected in reverse polarity.



WARNING

Input voltages higher than the maximum value accepted by the inverter (see "Specifications" in Section 9) may damage the inverter.

Although Solis inverters feature reverse polarity protection, prolonged connection in reverse polarity may damage these protection circuits and/or the inverter.

5.4.1.2 Leakage to ground

Measure leakage to ground to check for a DC ground fault.

5.4.1.2.1 Detection of leakage to ground

Solis inverters are transformer-less and do not have an array connection to ground.

Any measurement of a fixed voltage between ground and either the positive or negative string wiring indicates a leakage (ground fault) to ground and must be corrected prior to energizing the inverter or damage to the inverter may result.

To measure leakage to ground, perform the following steps:

1. Ensure that neither negative nor positive DC conductors are connected to the ground strip.
2. Measure each string positive connection to ground.
3. Measure each string negative connection to ground.
4. Verify the voltage is “floating”(slowly discharging toward 0V), not a consistent voltage to ground. Make sure you notice the units of the measurement. mV is not the same as V.

5.4.2 AC configuration

Verify AC configuration.

5.4.2.1 Measure VAC and frequency

Measure VAC and verify voltage is within local grid standards.

1. Measure each phase to ground (L-G).
2. Measure phases to the other phases in pairs (L-L). PH A to PH B, PH B to PH C and PH C to PH A.
3. If the meter is equipped, measure the frequency of each phase to ground.
4. Ensure each measurement is within local grid standards and the inverter specifications as noted in Section 9 “Specifications”.

5.4.2.2 Phase rotation test

A phase rotation test is recommended to ensure the phases have been connected in the appropriate order. Solis inverters do not require a specific phase rotation connection. However, the local utility may require a specific phase rotation or a record of the phase configuration of the installation.

5.4.3 DC Connections

Verify DC connections.

Lightly tug on each DC cable to ensure it is properly connected to the inverter.

5.4.4 AC Connections

Verify AC connections.

1. Lightly tug on each AC cable to ensure it is fully captured in the terminal.
2. Visually check for any stray strands that may not be inserted in the terminal.
3. Check to ensure the terminal screws are torque to correct specification table 3.1 .

6.1 Start-up procedure

To start-up the inverter, it is mandatory that the steps below are followed in the exact order outlined.

1. Ensure the commissioning checks in Section 5 have been performed.
2. Switch the AC switch **ON**.
3. Switch the DC switches **ON** one at a time. If the PV array (DC) voltage is higher than the inverter start-up voltage, the inverter will turn on. The red **DC POWER** LED and LCD will be continuously lit.
4. Solis inverters are powered from the DC side. When the inverter detects DC power that is within start-up and operating ranges, the inverter will turn on. After turn-on, the inverter will check internal parameters, sense and monitor AC voltage, frequency rate and the stability of the supply grid. During this period, the green **OPERATION** LED will flash and the LCD screen will show **INITIALIZING**. This tells the operator that the inverter is preparing to generate AC power.
5. After the locally mandated delay (300 seconds for IEEE-1547 compliant inverters), the inverter will start generating AC power. The green **OPERATION** LED will light continuously and the LCD screen will show **GENERATING**.



CAUTION

The inverter's surface temperature can reach up to 75°C (167°F). To avoid risk of burns, do not touch the surface when the inverter is in the operational mode. Additionally, the inverter must be installed out of the reach of children.

6.2 Shutdown procedure

To stop the inverter, it is mandatory that the steps below are followed in the exact order outlined

1. Press The **ENT** key to enter internal menus.
2. Navigate to **Advance Settings**.
3. Authorized Technicians will use the Password **0010** to enter the Advance Settings menu.
4. Enter the Advance Settings menu and scroll down to **Grid OFF/ON**.
5. Use the arrow keys to choose **GRID OFF**.
6. Technician will see the Green Operation LED go dark. The inverter may indicate a NO GRID alarm and the technician may see a Yellow Alarm LED illuminate. The RED Power LED will stay lit until dc power is removed.
7. Turn off the AC Switch to the OFF position.
8. Wait approximately 30 seconds and Switch the DC switch OFF.
9. Confirm all LED's switch OFF (~one (1) minute).



CAUTION

Although the inverter DC disconnect switch is in the OFF position and all the LED's are OFF, operators must wait five (5) minutes after the DC power source has been disconnected before opening the inverter cabinet. DC side capacitors can take up to five (5) minutes to dissipate all stored energy.

In normal operation, LCD screen alternatively shows inverter power and operation status (see Figure 6.1). The screen can be scrolled manually by pressing the UP/DOWN keys. Pressing the ENTER key gives access to Main Menu.




Figure 6.1 Operation Overview

6.3 Main Menu

There are four submenus in the Main Menu (see Figure 6.1):

1. **Information**
2. **Settings**
3. **Advanced Info.**
4. **Advanced Settings**

6.4 Information

The Solis three Phase Inverter main menu provides access to operational data and information. The information is displayed by selecting "Information" from the menu and then by scrolling up or down.

6. Normal operation

| Display | Duration | Description |
|---|----------|---|
| VPV_Total: 1000.0V IPV_Total: +99.0A | 10 sec | VPV_Total: Shows input voltage total. IPV_Total: Shows input current total. |
| V_A: 345.7V I_A: 109.0A | 10 sec | V_A: Shows the grid's voltage value. I_A: Shows the grid's current value. |
| V_C: 345.0V I_C: 109.8A | 10 sec | V_C: Shows the grid's voltage value. I_C: Shows the grid's current value. |
| Status: Generating Power: 1488W | 10 sec | Status: Shows instant status of the Inverter. Power: Shows instant output power value. |
| Rea_Power: 000Var App_Power: VA | 10 sec | Rea_Power: Shows the reactive power of the inverter. App_Power: Shows the apparent power of the inverter. |
| Grid Frequency F_Grid 50.06Hz | 10 sec | F_Grid: Shows the grid's frequency value. |
| Total Energy 0258458 kwh | 10 sec | Total generated energy value. |
| This Month: 0123kwh Last Month: 0123kwh | 10 sec | This Month: Total energy generated this month. Last Month: Total energy generated last month. |
| Today: 15.1kwh Yesterday: 13.5kwh | 10 sec | Today: Total energy generated today. Yesterday: Total energy generated yesterday. |
| Inverter SN 00000000000000 | 10 sec | Display series number of the inverter. |
| Work Mode: Volt-watt DRM NO.:08 | 10 sec | Work Mode: Shows current working mode. DRM NO.: Shows DRM Number. |
| I_DC01: +05.0A I_DC02: +04.9A ... I_DC20: +05.2A | 10 sec | I_DC01 : Shows input 01 current value. I_DC02 : Shows input 02 current value. ... I_DC20 : Shows input 20 current value. |

Table 6.1 Information list

6.4.1 Lock Screen

Pressing the ESC key returns to the Main Menu. Pressing the ENTER key locks (Figure 6.2(a)) or unlocks (Figure 6.2 (b)) the screen.



Figure 6.2 Locks and Unlocks the Screen of LCD

6.5 Settings


The following submenus are displayed when the Settings menu is selected:

1.Set Time

2.Set Address

6.5.1 Set Time

This function allows time and date setting. When this function is selected, the LCD will display a screen as shown in Figure 6.3.

The image shows a rectangular LCD screen with a light gray background. It displays two lines of text: the top line is 'NEXT=<ENT> OK=<ESC>' and the bottom line is '01-01-2019 16:37'. The text is in a black, sans-serif font.

NEXT=<ENT> OK=<ESC>
01-01-2019 16:37

Figure 6.3 Set Time

Press the UP/DOWN keys to set time and data. Press the ENTER key to move from one digit to the next (from left to right). Press the ESC key to save the settings and return to the previous menu.

6.5.2 Set Address

This function is used to set the address when muti inverters are connected to three monitoring. The address number can be assigned from "01"to "99"(see Figure 6.4). The default address number of Solis Three Phase Inverter is "01".

The image shows a rectangular LCD screen with a light gray background. It displays two lines of text: the top line is 'YES=<ENT> NO=<ESC>' and the bottom line is 'Set Address: 01'. The text is in a black, sans-serif font.

YES=<ENT> NO=<ESC>
Set Address: 01

Figure 6.4 Set Address

Press the UP/DOWN keys to set the address. Press the ENTER key to save the settings. Press the ESC key to cancel the change and return to the previous menu.

6.6 Advanced Info - Technicians Only



NOTE:

To access to this area is for fully qualified and accredited technicians only. Enter menu "Advanced Info." and "Advanced settings" (need password) .

Select "Advanced Info." from the Main Menu. The screen will require the password as below:

YES=<ENT> NO=<ESC>
Password:0000

Figure 6.5 Enter password

The default password is "0010". Please press "down" to move the cursor, press "up" to select the number.

After enter the correct password the Main Menu will display a screen and be able to access to the following information.

1. Alarm Message
2. Running message
3. Version
4. Daily Energy
5. Monthly Energy
6. Yearly Energy
7. Daily Records
8. Communication Data
9. Warning Message

6.6.1 Alarm Message

The display shows the 100 latest alarm messages (see Figure 6.6). Screens can be scrolled manually by pressing the UP/ DOWN keys. Press the ESC key to return to the previous menu.

Alm000: OV-G-V
T: 00-00 00:00 D: 0000

Figure 6.6 Alarm Message


6.6.2 Running Message

This function is for maintenance person to get running message such as internal temperature, Standard No.1,2,etc.

Screens can be scrolled manually by pressing the UP/DOWN keys.

6.6.3 Version

The screen shows the model version of the inverter. And the screen will show the software ver by pressing the UP and DOWN at the same time. (see Figure 6.7).




Model: 08
Software Version: D20001

Figure 6.7 Model Version and Software Version

6.6.4 Daily Energy


The function is for checking the energy generation for selected day.



YES=<ENT> NO=<ESC>
Select: 2019-01-01

Figure 6.8 Select date for daily energy

Press DOWN key to move the cursor to day, month and year, press UP key to change the digit. Press Enter after the date is fixed.




2019-01-01: 051.3kWh
2019-01-01: 061.5kWh

Figure 6.9 Daily energy

Press UP/DOWN key to move one date from another.

6.6.5 Monthly Energy


The function is for checking the energy generation for selected month.



YES=<ENT> NO=<ESC>
Select: 2019-01

Figure 6.10 Select month for monthly energy

Press DOWN key to move the cursor to day and month, press UP key to change the digit. Press Enter after the date is fixed.




2019-01: 0510kWh
2019-01: 0610kWh

Figure 6.11 Month energy

Press UP/DOWN key to move one date from another.

6.6.6 Yearly Energy


The function is for checking the energy generation for selected year.



YES=<ENT> NO=<ESC>
Select: 2019

Figure 6.12 Select year for yearly energy

Press DOWN key to move the cursor to day and year, press UP key to change the digit. Press Enter after the date is fixed.



2018: 0017513kWh
2017: 0165879kWh

Figure 6.13 Yearly energy


Press UP/DOWN key to move one date from another.

6.6.7 Daily Records

The screen shows history of changing settings. Only for maintenance personnel.

6.6.8 Communication Data

The screen shows the internal data of the Inverter (see Figure 6.14), which is for service technicians only.




01-05: 01 25 E4 9D AA
06-10: C2 B5 E4 9D 55

Figure 6.14 Communication Data

6.6.9 Warning Message

The display shows the 100 latest warn messages (see Figure 6.15). Screens can be scrolled manually by pressing the UP/ DOWN keys. Press the ESC key to return to the previous menu.



Msg000:
T: 00-00 00:00 D: 0000

Figure 6.15 Warning Message

6.7 Advanced Settings - Technicians Only



NOTE

To access to this area is for fully qualified and accredited technicians only.
Please follow 6.4 to enter password to access this menu.

Select Advanced Settings from the Main Menu to access the following options:

1. **Select Standard**
2. **Grid ON/OFF**
3. **Clear Energy**
4. **Reset Password**
5. **Power Control**
6. **Calibrate Energy**
7. **Special Settings**
8. **STD. Mode Settings**
9. **Restore Settings**
10. **HMI Update**
11. **External EPM set**
12. **Restart HMI**
13. **Debug Parameter**
14. **DSP Update**
15. **Compensation Set**
16. **I/V Curve**

6.7.1 Selecting Standard

This function is used to select the grid reference standard (see Figure 6.16).

YES=<ENT> NO=<ESC>
Standard:UL-480V-A

Figure 6.16

Selecting the “User-Def” menu will access the following sub-menu (see Figure 6.17).

→ OV-G-V1: 260V
OV-G-V1-T: 1.0S

Figure 6.17

Below is the range for each setting for use in the User-Def function. You may change the limit manually thus creating a custom grid profile by using this function.

| | |
|---------------------|---------------------|
| OV-G-V1: 236---335V | OV-G-F1: 60.2-63Hz |
| OV-G-V1-T: 0.1---9S | OV-G-F1-T: 0.1---9S |
| OV-G-V2: 248---341V | OV-G-F2: 61-63Hz |
| OV-G-V2-T: 0.1---1S | OV-G-F2-T: 0.1---9S |
| UN-G-V1: 173---236V | UN-G-F1: 57-59.5Hz |
| UN-G-V1-T: 0.1---9S | UN-G-F1-T: 0.1---9S |
| UN-G-V2: 132---219V | UN-G-F2: 57-59Hz |
| UN-G-V2-T: 0.1---1S | UN-G-F2-T: 0.1---9S |
| Startup-T: 10-600S | Restore-T: 10-600S |

Table 6.2 Setting ranges for User-Def



NOTE

The initial value of the User-Def standard is for reference only. It does not represent a correct value suitable for use.

| Setting value | 480V Rated (L-L) | 480V Rated (L-N) |
|---------------|-----------------------------------|-----------------------------------|
| Vup-Limit1 | $528 < V < 576$ | $305 < V < 333$ |
| Time1 | 1S | 1S |
| Vup-Limit2 | $V \geq 576$ | $V \geq 333$ |
| Time2 | 0.16S | 0.16S |
| Vdw-Limit1 | $288 \leq V < 422$ | $166 \leq V < 244$ |
| Time1 | 2S | 2S |
| Vdw-Limit2 | $V < 288$ | $V < 166$ |
| Time2 | 0.16S | 0.16S |
| Fup-Limit1 | $60.5\text{Hz} < F < 62\text{Hz}$ | $60.5\text{Hz} < F < 62\text{Hz}$ |
| Time1 | 2S | 2S |
| Fup-Limit2 | $F > 62\text{Hz}$ | $F > 62\text{Hz}$ |
| Time2 | 0.16S | 0.16S |
| Fdw-Limit1 | $57\text{Hz} < F < 59.5\text{Hz}$ | $57\text{Hz} < F < 59.5\text{Hz}$ |
| Time1 | 2S | 2S |
| Fdw-Limit2 | $57\text{Hz} < F$ | $57\text{Hz} < F$ |
| Time2 | 0.16S | 0.16S |

Table 6.3 Baseline Inverter Settings

6.7.2 Grid ON/OFF

This function is used to start up or stop the power generation of Solis Three Phase Inverter (see Figure 6.18).




Figure 6.18 Set Grid ON/OFF

Screens can be scrolled manually by pressing the UP/DOWN keys. Press the ENTER key to save the setting. Press the ESC key to return to the previous menu.

6.7.3 Clear Energy


Clear Energy can reset the history yield of inverter



These two functions are applicable by maintenance personnel only, wrong operation will prevent the inverter from working properly.

6.7.4 Reset Password

This function is used to set the new password for menu "Advanced info." and "Advanced information" (see Figure 6.19).

A screenshot of a menu box with a light purple background. It contains the text 'YES=<ENT> NO=<ESC>' and 'Password: 0000'.

YES=<ENT> NO=<ESC>
Password: 0000

Figure 6.19 Set new password

Enter the right password before set new password. Press the DOWN key to move the cursor, Press the UP key to revise the value. Press the ENTER key to execute the setting. Press the ESC key to return to the previous menu.

6.7.5 Power Control

Active and reactive power can be set through power setting button.

There are 5 item for this sub menu:

1. Set output power
2. Set Reactive Power
3. Out_P With Restore
4. Rea_P With Restore
5. Select PF Curve



This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6.7.6 Calibrate Energy

Maintenance or replacement could clear or cause a different value of total energy. Use this function could allow user to revise the value of total energy to the same value as before. If the monitoring website is used the data will be synchronous with this setting automatically. (see Figure 6.20).

YES=<ENT> NO=<ESC>
Energy:0000000kWh

Figure 6.20 Calibrate energy

Press the DOWN key to move the cursor, Press the UP key to revise the value. Press the ENTER key to execute the setting. Press the ESC key to return to the previous menu.

6.7.7 Special Settings



This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6.7.8 STD Mode Settings



NOTE

This section is applicable to maintenance personnel only.

Selecting "STD Mode. Settings" displays the sub-menu shown below:

1. Working Mode Set
2. Power Rate Limit
3. Freq Derate Set
4. 10mins Voltage Set
5. Power Priority
6. Initial Settings
7. Voltage PCC Set
8. Freq-Watt

6.7.8.1 Working Mode Set

There are TWO situations with different grid standards selected.

6.7.8.1.1 With UL Standard selected



NOTE

The following modes are for "UL-480V-A".

Solis US version inverters have Seven working modes:

1. NULL
2. Volt-watt
3. Volt-Var
4. Fixed-PF
5. Reac-power
6. Power-PF
7. VgWatt-UL

Based on UL1741SA, working mode 1,3,4,7 can be used by grid operator.

1.NULL

Description: Inverter is not under any working mode.

2. Volt-Watt (Not Required)

Description: Inverter will change the active output power based on voltage change.

Note: This Setting is NOT required by UL1741SA Standards.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

3. Volt-Var (Default)

Description: Inverter will change the reactive output power based on voltage change.




Figure 6.21 Volt-VAR curve for Q (V)

Default Settings for UL1741SA:

Q1: (0-60%) Default +30% Q4: (-60%-0%) Default -30%

Rated 480V Grid

V1:(221-279V) Default 242V V2: (221-279V) Default 273V

V3:(277-320V) Default 281V V4: (277-320V) Default 305V

Voltage1 : 242V
Voltage2 : 273V

Figure 6.22 Volt-VAR

4.Fixed-PF

Description: Inverter will output power with fixed power factor.

Setting Range: -0.8 to +0.8

Default value is PF = 1




Figure 6.23 Fixed-PF




Figure 6.24 PF Range

5. Reac-power (Not Required)

Description: Inverter will generate reactive power based on changing output power.

Note: This Setting is NOT required by UL1741SA Standards.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6. P-factor (Not Required)

Description: Inverter will change power factor based on changing output power.

Note: This Setting is NOT required by UL1741SA Standards.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

7.VgWatt-UL

Description: Inverter will change the active output power based on voltage change.

Note: This is the Volt-Watt Setting for UL1741SA Standards.




Figure 6.25 Volt-Watt characteristic

Default Settings for UL1741SA:

Rated 480V Grid

V1:less than V2

V2:less than Vstart

V3 (Vstart): (277-333V) Default305V

V4 (Vstop): (305-360V) Default 333V

P1:100% P2:100% P3: 100% P4:0%

Voltage1 : 254V
P-Limit1 : 100%

Figure 6.26 VgWatt-UL

6.7.8.1.2 With Rule21 Standard selected



NOTE

The following modes are for "R21P3-48A".

Solis US version inverters have Ten working modes:

1. **NULL**
2. **Volt-watt**
3. **Volt-Var**
4. **Fixed-PF**
5. **Reac-power**
6. **Power-PF**
7. **VgWatt-UL**

Based on Rule21, working mode 1,2,3,4 can be used by grid operator.



NOTE

The other three working mode "P1-V-Watt", "P1-V-Var" and "P1-V-P&V-Q" are NOT applicable for settings.

1.NULL (Mode Reset)

Description: Inverter is not under any working mode.

2. Volt-Watt

Description: Inverter will change the active output power based on voltage change.

Note: This is the Volt-Watt Setting for Rule21 Standards.




Figure 6.27 Volt-Watt characteristic

Default Settings for Rule21 Standards:

Rated 480V Grid

V1:less than Vstart

V2 (Vstart): (221-304V) Default 293V


V3 (Vstop): (277-332V) Default 304V

V4: larger than Vstop

P1:100% P2:100% P3: 0% P4:0%

3. Volt-Var

Description: Inverter will change the reactive output power based on voltage change.



Default Settings for Rule21 Standard:

Q1: (0-60%) Default +30% Q4: (-60%-0%) Default -30%

Rated 480V Grid

V1:(221-277V) Default 254V V2: (221-304V) Default 268V

V3:(277-332V) Default 286V V4: (277-332V) Default 296V

Voltage1 : 254V
Voltage2 : 268V

Figure 6.29 Volt-VAR

4.Fixed-PF

Description: Inverter will output power with fixed power factor.

Setting Range: -0.8 to +0.8

Default value is PF = 1

YES=<ENT> NO=<ESC>
Power Factor: +1. 00

Figure 6.30 Fixed-PF




Figure 6.31 PF Range

5. Reac-power (Not Required)

Description: Inverter will generate reactive power based on changing output power.

Note: This Setting is NOT required by Rule21 Standards.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6. P-factor (Not Required)

Description: Inverter will change power factor based on changing output power.

Note: This Setting is NOT required by Rule21 Standards.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

7. VgWatt-UL (Not Required)

Description: Inverter will change the active output power based on voltage change.

Note: This Setting is NOT required by Rule21 Standards.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

8. Enable both Volt-Var and Volt-Watt modes


Description: Rule21 requires both Volt-var and Volt-watt modes can be enabled.

To set both modes (Volt-var in high priority)

Step 1: Select and set Volt-watt mode at first.

Step 2: Enter "Working Mode" again and select and set Volt-var mode then.

Step 3: To check the priority, a new mode will appear as "V-Q & V-P" which indicates (Q) Volt-var is in high priority.



YES=<ENT> NO=<ESC>
Work Mode: V-Q & V-P


Figure 6.32 Work Mode

To set both modes (Volt-watt in high priority)

Step 1: Select and set Volt-var mode at first.

Step 2: Enter "Working Mode" again and select and set Volt-watt mode then.

Step 3: To check the priority, a new mode will appear as "V-P & V-Q" which indicates (P) Volt-watt is in high priority.



YES=<ENT> NO=<ESC>
Work Mode: V-P & V-Q

Figure 6.33 Work Mode

To reset dual-mode or exit the dual-mode situation

Step 1: Select "Null" mode at first.

Step 2: Enter "Working Mode" again. Redo above dual-mode setting steps to reset OR set other modes to exit dual-mode situation.



NOTE

To check the Volt-watt and Volt-var priority, simply enter the working modes.
V-Q&V-P indicates Volt-Var First V-P&V-Q indicates Volt-Watt First

6.7.8.2 Power Rate Limit

This function is used for change Power Ramp-up rate. When inverter start up or input string MPPT changes, inverter power ramp-up rate is limited in this menu.

The default setting is stop (disable).

The setting range from 10% to 600%, means inverter power change rate per minute.

Values are not allowed to change. If they are set, they may not conform to the UL1741SA standard.

Power Rate:016%
RateP_Sts-US:STOP

Figure 6.34 Power Rate Limit

6.7.8.3 Freq Derate Set

This setting is applicable when UL Standards are selected.

There are 5 derate modes in this menu. When operating under standard UL-1741 limits, modes 00 to 03 are disabled. Mode 04 is used for UL1741SA frequency derating setting.

This sets the f_{start} and f_{stop} point.

The default setting is 00, means this function is disabled.

Derate Mode: 04
OV-F-Start: 60. 20Hz

Figure 6.35 Freq Derate Set




Figure 6.39 Freq-Watt characteristic

Over frequency load shedding f_{start} range 60~62Hz, default setting 60.2Hz

f_{stop} can set the scope: 61-64Hz, the default setting 62Hz.

Press the Enter key to select the mode or frequency.

Press Up/Down to set. Press ESC to save the settings.

6.7.8.4 10mins Voltage Set

This function is disabled and not used for the US.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6.7.8.5 Power Priority

This setting is used to set the priority between Active Power Control (Watt) and Reactive Power Control (Var).

YES=<ENT> NO=<ESC>
Select: Var First

Figure 6.36 Power Priority

Two options are available: Watt First and Var First.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6.7.8.6 Initial Settings

In initial settings it will reset each work mode from 6.5.8.1 to 6.5.8.4 back to default.

Work Mode Default
Power Rate Default

Figure 6.37 Initial Settings

6.7.8.7 Voltage PCC Set

Set the voltage at the PCC point.

This setting is required by RULE 21 requirements.

PCC: Point of Common Coupling, the point where a Local EPS is connected to an Area EPS.



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6.7.8.8 Freq-Watt

This setting is used to control real power based on the frequency excursion

This setting is applicable when Rule21 Standards are selected.

→ Start Freq: 60.50Hz
WGradient: 040%

Figure 6.38 Freq-Watt (1)

Start Freq: This is the frequency that active power reduction starts.

WGradient: This is the active power reduction rate in terms of the frequency.

Stop Freq: This is the frequency that stops the correction cycle.

Hysteresis: This indicates whether hysteresis is enabled.




Figure 6.39 Freq-Watt (2)



NOTE

This function is for maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6.7.9 Restore Settings



NOTE

This section is applicable to maintenance personnel only.

Selecting “Restore Settings” displays the option shown below:

Are you sure?
YES=<ENT> NO=<ESC>

Figure 6.40

Press the ENTER key to reset to factory defaults.

Press the ESC key to return to the previous menu.

6.7.10 HMI Updater



NOTE

This section is applicable to maintenance personnel only.

Selecting “Updater” displays the sub-menu shown below:

HMI Current Ver.: 02
YES=<ENT> NO=<ESC>

Figure 6.41

Updater is for updating LCD firmware. Press the ENTER key to start the process.
Press the ESC key to return to the previous menu.

6.7.11 External EPM Set

This function is turned on when the EPM is external.

YES=<ENT> NO=<ESC>
Fail Safe Set:ON

Figure 6.42 Set the Fail Safe ON/OFF

6.7.12 Restart HMI

The function is used for restart the HMI.



NOTE

This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6.7.13 Debug Parameter



NOTE

This section is applicable to maintenance personnel only.

Debug Parameter as shown as below:

```
→ S16DAT1: +0000
  S16DAT2: +0000
  S16DAT3: +0000
  S16DAT4: +0000
  S16DAT5: +0000
  S16DAT6: +0000
  S16DAT7: +0000
  S16DAT8: +0000
```

Figure 6.43

Press the UP/DOWN keys to scroll through items. Press the ENTER key to select.

Press the DOWN key to scroll and press the UP key to change the value.

Press the ENTER key to save the setting. Press the ESC key to cancel.

changes and return to the previous menu.

6.7.14 FAN Test



NOTE

This section is applicable to maintenance personnel only.

Selecting “Fan Test” displays the sub-menu shown below:

```
Are you sure?
YES=<ENT> NO=<ESC>
```

Figure 6.44

Fan Test is a factory test function. Press the ENTER key to start the test.

Press the ESC key to return to the previous menu.

6.7.14 DSP Update

The function is used for update the DSP.



NOTE

This function is applicable by maintenance personnel only, wrong operation will prevent the inverter from reaching maximum power.

6.7.15 Compensation Set

This function is used to calibrate inverter output energy and voltage. It will not impact the energy count for inverter with RGM.

Two sections are included: Power Parameter and Voltage Parameter.

The screen shows:

YES=<ENT> NO=<ESC>
Power para: 1. 000

Figure 6.45 Power Rate Limit

Press the Down key to move the cursor.

Press the Up key to change the digit.

Please press the Enter to save the setting and press the ESC key to return to the previous menu.




NOTE

This setting is used for grid operators, do not change this setting unless specifically instructed to.

6.7.16 I/V Curve

This function is used to scan the I/V characteristic curves of each PV strings.




→ Set I/V Curve
I/V Curve Scan

Figure 6.46 I/V Curve

6.7.16.1 Set I/V Curve

This setting can set the scanning voltage start point and the voltage interval.



Start_V: 850V
Interval_V: 010V

Figure 6.47 Set I/V Curve


Start_V: The start voltage of the I/V scan. (Adjustable from 300V-1000V)

Interval_V: The scanning voltage interval. (Adjustable from 1-100V)

In total, 60 data points can be scanned.

6.7.16.2 I/V Curve Scan


Press "ENT" to start the I/V curve scan.



Scanning...01

Figure 6.48 I/V Curve Scan (1)

After it is completed, the screen will display "Scan OK" and then enter the following section.



Select String No.: 01

Figure 6.49 I/V Curve Scan (2)



01_850V: 9.56A
02_860V: 9.44A

Figure 6.50 I/V Curve Scan (3)

6.8 AFCI function

Solis inverters have the built-in AFCI function which can detect the arc fault on the DC circuit and shut down the inverter to prevent a fire disaster.

6.8.1 Enable the AFCI function

The AFCI function can be enabled in the following.

Path: Advanced Setting -> Password: 0010 -> Special Settings -> AFCI Set -> AFCI ON/OFF -> ON




Figure 6.51 Set AFCI



WARNING

The "AFCI Level" is reserved for Solis technicians ONLY. Do not change the sensitivity otherwise it will lead to frequent false alarms or malfunctions. Solis is not responsible for any further damages caused by unauthorized modifications.



NOTE

The setting corresponds to the current status as well which can be used to inspect the ON/OFF state of the AFCI function.

6.8.2 Arc Fault

During the normal operation, if an DC arc is detected, the inverter will shut down and give out the following alarm:

ARC-FAULT
Restart Press ESC 3s

Figure 6.52 Arc Fault

Installer needs to thoroughly inspect the DC circuit to ensure all the cables are correctly fastened.

Once the DC circuit issue has been fixed or it is confirmed to be OK, press "ESC" for 3s and wait for the inverter to restart.

Solis Three Phase Inverter does not require any regular maintenance. However, cleaning the dust on heat-sink will help the inverter to dissipate the heat and increase its life time. The dust can be removed with a soft brush.



CAUTION

Do not touch the inverter's surface when it is operating. Some parts of the inverter may be hot and cause burns. Turn off the inverter (refer to Section 6.2) and wait for a cool-down period before any maintenance or cleaning operation.

The LCD and the LED status indicator lights can be cleaned with a damp cloth if they are too dirty to be read.



NOTE

Never use any solvents, abrasives or corrosive materials to clean the inverter.

7.1 Anti-PID Function

Solis inverter integrates optional Anti-PID module and it can recover the PID effect during night thus protect the PV system from degradation.




Figure 7.1

The Anti-PID module repairs the PID effect of the PV model at night. When operating, the inverter LCD screen displays "PID-repairing" information, and the red light is on. The Anti-PID function is always ON when AC is applied.

If maintenance is required and turn off the AC switch can disable the Anti-PID function.



WARNING

The PID function is automatic. When the DC bus voltage is lower than 50Vdc, the PID module will start creating 450 Vdc between PV- and ground. No need any control or settings



NOTE

If you need to maintain the inverter at night, please turn off the AC switch first, then turn off the DC switch, and wait 5 minutes before you do other operations.

7.2 Fan Maintenance

If the fan does not work properly, the inverter will not be cooled effectively, and it may affect the inverter operation. A warning message will be displayed on the LCD. Therefore, it is necessary to clean or replace a broken fan as follows:

1. Turn off the "Grid ON/OFF" switch on the inverter LCD (Section 6.2).
2. Disconnect the AC power.
3. Turn the DC switch to "OFF" position.
4. Wait for 15 minutes at least.
5. Remove the 4 screws on the fan plate and pull out the fan assembly slowly.



Figure 7.2

6. Disconnect the fan connector carefully and take out the fan.




Figure 7.3

7. Clean or replace the fan. Assemble the fan on the rack.
8. Connect the electrical wire and reinstall the fan assembly. Restart the inverter.

8.1 Current Alarm

8.1.1 Running messages

Running messages can be viewed on the screen including any current alarms.

8.2 Alarm History

8.2.1 Viewing alarm history

Refer to LCD Operation 6.6.8 for instructions on viewing Alarm History.

8.3 Error Messages



NOTE

The first step to clearing alarms as listed in Table 9, is to reset the inverter. To reset the inverter, turn off the inverter (refer to Section 6.2) and wait for five (5) minutes before restarting it (refer to Section 6.1). If the failure persists, please first contact your local distributor and then Solis Support Service.

If you need to contact Solis Support Service at <http://www.ginlong.com/us>

Please have the following information available when contacting technical support:

1. Inverter serial number
2. The inverter distributor/dealer (if available)
3. Installation date
4. The description of problem (e.g., the alarm message displayed on the screen and the status of the screen status indicator lights. Other readings obtained from the Information sub menu (refer to Section 6.4) will also be helpful.)
5. PV array configuration (e.g. number of panels, panel capacity, number of strings, etc.)
6. Your contact details

8.3.1 Troubleshooting guide

Solis inverters are designed in accordance with international grid standards, safety standards and electromagnetic compatibility requirements. Before delivery to the customer, the inverter has been subjected to intensive testing to ensure its optimal operation and reliability.

In case of failure, the screen may display an alarm message, stop feeding energy into the grid or both. Typical failure descriptions and their corresponding alarm messages are listed in Table 9 on the following pages.

| Alarms | Cause | Solution |
|---|--|---|
| No Information (Blank Screen) | <ul style="list-style-type: none"> • Input voltage low/missing • Polarity reversed • Main board damaged | <p>Test – DC switch OFF</p> <ul style="list-style-type: none"> • Check PV connections • Check polarity • Check voltage >200V <p>Test – DC Switch ON</p> <ul style="list-style-type: none"> • Check voltage >200V • If DC voltage is “0” replace inverter |
| Initializing (Inverter stuck in this mode) | <ul style="list-style-type: none"> • Inverter is waiting for driving signal | <p>Test – DC switch OFF</p> <ul style="list-style-type: none"> • Check PV connections • Check polarity • Check voltage >200V <p>Test – DC Switch ON</p> <ul style="list-style-type: none"> • Check voltage >200V • A cable may have been damaged or loosened in shipping replace inverter |
| OV-G-V: Over Grid Voltage | <ul style="list-style-type: none"> • Inverter detects grid voltage as too high | <p>Test – DC switch OFF</p> <ul style="list-style-type: none"> • Check AC at the inverter • If AC measures high, adjust upper limit with permission from utility <p>Test – DC Switch ON, full power</p> <ul style="list-style-type: none"> • Check AC at inverter test points • Compare with LCD • If AC measures high, cables between inverter and interconnect are too small • Check ampacity and voltage drop calculations |
| UN-G-V: Under Grid Voltage | <ul style="list-style-type: none"> • Inverter detects grid voltage as too low | <p>Test – DC switch OFF</p> <ul style="list-style-type: none"> • Check AC at the inverter test points • If AC measures low, adjust lower limit with permission from utility • Check LCD voltage reading, may be a bad measurement circuit <p>Test – DC Switch ON</p> <ul style="list-style-type: none"> • Check grid standard • Replace inverter |
| UN-BUS: DC BUS voltage is too low | <ul style="list-style-type: none"> • Inverter detects low DCV on internal bus | <p>Test</p> <ul style="list-style-type: none"> • Measure DC and AC voltages • Compare with LCD • Replace Inverter • Internal damage • Wire came loose during shipping |

| Alarms | Cause | Solution |
|------------------------------------|--|--|
| OV-G-F: Over Grid Frequency | <ul style="list-style-type: none"> Inverter detects grid Frequency as too high | <p>Test – DC switch OFF</p> <ul style="list-style-type: none"> Check frequency at the inverter test points If Frequency measures high, adjust upper limit with permission from utility Check LCD reading, may be a bad measurement circuit <p>Test – DC Switch ON</p> <ul style="list-style-type: none"> Check grid standard Replace inverter |
| NO-GRID | <ul style="list-style-type: none"> Inverter does not detect the grid | <p>Test – DC switch OFF</p> <ul style="list-style-type: none"> Check AC at the inverter test points L-L, L-GND Check LCD reading, may be a bad measurement circuit <p>Test – DC Switch ON</p> <ul style="list-style-type: none"> Check grid standard Replace inverter |
| OV-DC: DC voltage is too high | <ul style="list-style-type: none"> Inverter detects High DC Voltage | <p>Test – DC switch OFF</p> <ul style="list-style-type: none"> Check DC at the inverter test points If DC Voltage is high, check string configuration <p>Test – DC Switch ON</p> <ul style="list-style-type: none"> Check LCD reading, may be a bad measurement circuit Replace inverter |
| OV-BUS: DC BUS voltage is too high | <ul style="list-style-type: none"> Inverter detects High DC Voltage on internal bus | <p>Test</p> <ul style="list-style-type: none"> Measure DC and AC voltages Compare with LCD Replace Inverter Internal damage Wire came loose during shipping |
| GRID-INTF: Grid unstable | <ul style="list-style-type: none"> Inverter detects grid instability, internal fault current high | <p>Test – With DC Switch OFF</p> <ul style="list-style-type: none"> Measure AC voltage Test AC line for THD <p>Test – With DC Switch ON</p> <p>Test AC line for THD</p> <ul style="list-style-type: none"> Multiple inverters/turn one off Impedance matching adjustment or box Internal damage Wire came loose in shipping |

| Alarms | Cause | Solution |
|--|--|---|
| INI-FAULT: Initialization Protection | <ul style="list-style-type: none"> Master and Slave DSP have different values | Reset Inverter <ul style="list-style-type: none"> DC switch OFF Wait until all lights/LCD turn off DC switch ON Replace inverter |
| OV-TEM: Temperature Protection | <ul style="list-style-type: none"> Inverter detects high ambient temperature >60C | Inspect installation <ul style="list-style-type: none"> Check heatsink for obstructions/ventilation Is inverter in direct sunshine Measure ambient temperature near inverter If temp is in range replace inverter |
| PV ISO-PRO 01/02: Ground Protection | <ul style="list-style-type: none"> Inverter detects low DC insulation resistance | Inspect installation <ul style="list-style-type: none"> Reset inverter Note weather conditions when alarm occurs Measure insulation resistance If normal, measure in SAME weather as alarm Physically check cables Replace inverter |
| ARC-FAULT | <ul style="list-style-type: none"> Inverter detects arc in DC circuit | Inspect installation <ul style="list-style-type: none"> Check cable with string tester Physically check cables Inspect panel junction boxes Inspect cable connections Reset inverter Replace inverter |
| Screen OFF with DC applied | <ul style="list-style-type: none"> Inverter internally damaged | <ul style="list-style-type: none"> Do not turn off the DC switches as it may damage the inverter. Please wait for sunset and confirm the string current is less than 0.5A with a clip-on ammeter and then turn off the DC switch. String current above 0.5A is under load. Note: Damage due to wrong connections or fire caused by removing string wires or opening fuse holders under load is not covered in the device warranty. |
| Reve-DC | <ul style="list-style-type: none"> One of the DC string is reversely connected OR different number of modules are connected to the string inputs (Threshold varies between different conditions) | <ul style="list-style-type: none"> Please check the inverters' PV string polarity, if there are strings reversely connected wait for the night when the solar irradiance is low and the PV string current down below 0.5A. Turn off the two DC switches and fix the polarity issue. If string polarity is correct, please confirm that all the PV strings have the same number of modules. If not, please modify the system configuration. |

Table 8.1 Fault messages and descriptions

9. Specifications

| Model | S5-GC75K-US |
|--|---|
| Max. DC input voltage (Volts) | 1000 |
| Rated DC voltage (Volts) | 600 |
| Start-up voltage (Volts) | 195 |
| MPPT voltage range (Volts) | 180...1000 |
| Full load MPPT voltage range (Volts) | 550...850 |
| Max. input current (Amps) | 8x32 |
| Max short circuit input current (Amps) | 8x50 |
| MPPT number/Max input strings number | 8/16 |
| Rated output power (Watts) | 75000 |
| Max. output power (Watts) | 75000 |
| Max. apparent output power (VA) | 75000 |
| Rated grid voltage (Volts) | 3/PE~480 |
| Rated output current (Amps) | 90.2 |
| Power Factor (at rated output power) | 0.8leading~0.8lagging |
| THDi (at rated output power) | <3% |
| Rated grid frequency (Hertz) | 60 |
| Max. efficiency | 98.7% |
| EU efficiency | 98.3% |
| MPPT efficiency | 99.5% |
| Dimensions (W*H*D) | 1065x567x344.5 (mm) / 41.9x22.3x13.5 (inch) |
| Weight | 85kg / 187lbs |
| Topology | Transformerless |
| Self consumption (night) | < 2W |
| Operating ambient temperature range | -13...140°F / -25°C...+60°C |
| Relative humidity | 0~100% |
| Ingress protection | TYPE 4X |
| Noise emission | ≤65dB(A) |
| Cooling concept | Intelligent redundant cooling |
| Max.operation altitude | 13120ft / 4000m |
| Compliance | UL1741, IEEE 1547-2018, UL1699B, UL1998, FCC, UL1741SA, UL1741SB, California Rule 21, Heco Rule 14H, CAN/CSA C22.2107.1-1 |
| DC connection | MC4 |
| AC connection | OT Terminal connectors (Max.185mm²) |
| Display | LCD |
| Communication connections | RS485, Optional: WIFI, Cellular, Ethernet |
| Warranty | 10 years standard (extend to 20 years) |

9. Specifications

| Model | S5-GC80K-US |
|--|---|
| Max. DC input voltage (Volts) | 1000 |
| Rated DC voltage (Volts) | 600 |
| Start-up voltage (Volts) | 195 |
| MPPT voltage range (Volts) | 180...1000 |
| Full load MPPT voltage range (Volts) | 550...850 |
| Max. input current (Amps) | 9x32 |
| Max short circuit input current (Amps) | 9x50 |
| MPPT number/Max input strings number | 9/18 |
| Rated output power (Watts) | 80000 |
| Max. output power (Watts) | 80000 |
| Max. apparent output power (VA) | 80000 |
| Rated grid voltage (Volts) | 3/PE~480 |
| Rated output current (Amps) | 96.2 |
| Power Factor (at rated output power) | 0.8leading~0.8lagging |
| THDi (at rated output power) | <3% |
| Rated grid frequency (Hertz) | 60 |
| Max. efficiency | 98.7% |
| EU efficiency | 98.3% |
| MPPT efficiency | 99.5% |
| Dimensions (W*H*D) | 1065x567x344.5 (mm) / 41.9x22.3x13.5 (inch) |
| Weight | 85kg / 187lbs |
| Topology | Transformerless |
| Self consumption (night) | < 2W |
| Operating ambient temperature range | -13...140°F / -25°C...+60°C |
| Relative humidity | 0~100% |
| Ingress protection | TYPE 4X |
| Noise emission | ≤65dB(A) |
| Cooling concept | Intelligent redundant cooling |
| Max.operation altitude | 13120ft / 4000m |
| Compliance | UL1741, IEEE 1547-2018, UL1699B, UL1998, FCC, UL1741SA, UL1741SB, California Rule 21, Heco Rule 14H, CAN/CSA C22.2107.1-1 |
| DC connection | MC4 |
| AC connection | OT Terminal connectors (Max.185mm²) |
| Display | LCD |
| Communication connections | RS485, Optional: WIFI, Cellular, Ethernet |
| Warranty | 10 years standard (extend to 20 years) |

9. Specifications

| Model | S5-GC90K-US |
|--|---|
| Max. DC input voltage (Volts) | 1000 |
| Rated DC voltage (Volts) | 600 |
| Start-up voltage (Volts) | 195 |
| MPPT voltage range (Volts) | 180...1000 |
| Full load MPPT voltage range (Volts) | 550...850 |
| Max. input current (Amps) | 10x32 |
| Max short circuit input current (Amps) | 10x50 |
| MPPT number/Max input strings number | 10/20 |
| Rated output power (Watts) | 90000 |
| Max. output power (Watts) | 90000 |
| Max. apparent output power (VA) | 90000 |
| Rated grid voltage (Volts) | 3/PE~480 |
| Rated output current (Amps) | 108.3 |
| Power Factor (at rated output power) | 0.8leading~0.8lagging |
| THDi (at rated output power) | <3% |
| Rated grid frequency (Hertz) | 60 |
| Max. efficiency | 98.8% |
| EU efficiency | 98.2% |
| MPPT efficiency | 99.5% |
| Dimensions (W*H*D) | 1065x567x344.5 (mm) / 41.9x22.3x13.5 (inch) |
| Weight | 85kg / 187lbs |
| Topology | Transformerless |
| Self consumption (night) | < 2W |
| Operating ambient temperature range | -13...140°F / -25°C...+60°C |
| Relative humidity | 0~100% |
| Ingress protection | TYPE 4X |
| Noise emission | ≤65dB(A) |
| Cooling concept | Intelligent redundant cooling |
| Max.operation altitude | 13120ft / 4000m |
| Compliance | UL1741, IEEE 1547-2018, UL1699B, UL1998, FCC, UL1741SA, UL1741SB, California Rule 21, Heco Rule 14H, CAN/CSA C22.2107.1-1 |
| DC connection | MC4 |
| AC connection | OT Terminal connectors (Max.185mm²) |
| Display | LCD |
| Communication connections | RS485, Optional: WIFI, Cellular, Ethernet |
| Warranty | 10 years standard (extend to 20 years) |

9. Specifications

| Model | S5-GC100K-US |
|--|---|
| Max. DC input voltage (Volts) | 1000 |
| Rated DC voltage (Volts) | 600 |
| Start-up voltage (Volts) | 195 |
| MPPT voltage range (Volts) | 180...1000 |
| Full load MPPT voltage range (Volts) | 550...850 |
| Max. input current (Amps) | 10x32 |
| Max short circuit input current (Amps) | 10x50 |
| MPPT number/Max input strings number | 10/20 |
| Rated output power (Watts) | 100000 |
| Max. output power (Watts) | 100000 |
| Max. apparent output power (VA) | 100000 |
| Rated grid voltage (Volts) | 3/PE~480 |
| Rated output current (Amps) | 120.3 |
| Power Factor (at rated output power) | 0.8leading~0.8lagging |
| THDi (at rated output power) | <3% |
| Rated grid frequency (Hertz) | 60 |
| Max. efficiency | 98.8% |
| EU efficiency | 98.2% |
| MPPT efficiency | 99.5% |
| Dimensions (W*H*D) | 1065x567x344.5 (mm) / 41.9x22.3x13.5 (inch) |
| Weight | 85kg / 187lbs |
| Topology | Transformerless |
| Self consumption (night) | < 2W |
| Operating ambient temperature range | -13...140°F / -25°C...+60°C |
| Relative humidity | 0~100% |
| Ingress protection | TYPE 4X |
| Noise emission | ≤65dB(A) |
| Cooling concept | Intelligent redundant cooling |
| Max.operation altitude | 13120ft / 4000m |
| Compliance | UL1741, IEEE 1547-2018, UL1699B, UL1998, FCC, UL1741SA, UL1741SB, California Rule 21, Heco Rule 14H, CAN/CSA C22.2107.1-1 |
| DC connection | MC4 |
| AC connection | OT Terminal connectors (Max.185mm²) |
| Display | LCD |
| Communication connections | RS485, Optional: WIFI, Cellular, Ethernet |
| Warranty | 10 years standard (extend to 20 years) |

| Parts | Torque |
|--------------------------|----------------|
| Cover screws | 1.5-1.7 ft.lbs |
| Ground screws (Cover) | 4.4-6.0 ft.lbs |
| Ground screws (Internal) | 17-21 ft.lbs |
| AC terminals | 17-21 ft.lbs |

10.1 Temperature Derating




Figure 10.1 For all models of inverter

Comments:

A thermal sensor inside the inverter is calibrated to determine ambient temperature. All inverters will begin a sloped derate at 50°C ending at 60% output power at 60°C. Temperatures above 60°C or below -25°C will de-rate to 0% output power. Inverter will also de-rate output power when a fan is blocked or non-operational. In this case, a warning message will appear on the front panel LCD.

10.2 Input Voltage Derating




Figure 10.2 For all models of inverter

10.3 Output Voltage Derating






Figure 10.3 For all models of inverter



10.4 P-Q Capabilities at Nominal Output Power

Inverter is capable providing reactive power of $\pm 60\text{kVAR}$ at nominal grid voltage and rated ambient temperature. Chart below details inverter reactive power capabilities at various input voltages and various ambient temperature condition.





10.5 P-Q Capabilities at Nominal Output Power

Inverter is capable providing reactive power of $\pm 54\text{kVAR}$ at nominal grid voltage and rated ambient temperature. Chart below details inverter reactive power capabilities at various input voltages and various ambient temperature condition.





10.6 P-Q Capabilities at Nominal Output Power

Inverter is capable providing reactive power of $\pm 48\text{kVAR}$ at nominal grid voltage and rated ambient temperature. Chart below details inverter reactive power capabilities at various input voltages and various ambient temperature condition.



10.7 P-Q Capabilities at Nominal Output Power

Inverter is capable providing reactive power of $\pm 45\text{kVAR}$ at nominal grid voltage and rated ambient temperature. Chart below details inverter reactive power capabilities at various input voltages and various ambient temperature condition.



10.8 Default Grid Setting for UL-480-18

| Parameter | Range | Default | Description |
|-------------------------------|------------------------------|----------------------|--|
| OV-G-V01 L-L | 528-576 V | 528 V | Set grid over-voltage protection 01 value L-L |
| OV-G-V01 L-N | 304.8-332.6 V | 304.8 V | Set grid over-voltage protection 01 value L-N |
| OV-G-V01-T | 1-13 S | 13 S | Grid over-voltage protection 01 trip time |
| OV-G-V02 L-L | 528-624 V | 576 V | Set grid over-voltage protection 02 value L-L |
| OV-G-V02 L-N | 304.8-360.3 V | 332.6 V | Set grid over-voltage protection 02 value L-N |
| OV-G-V02-T | | 0.12 S | Grid over-voltage protection 02 trip time |
| OV-G-V03 L-L | 528-624 V | 576 V | Set grid over-voltage protection 03 value L-L |
| OV-G-V03 L-N | 304.8-360.3 V | 332.6 V | Set grid over-voltage protection 02 value L-L |
| OV-G-V03-T | | 0.12 S | Grid over-voltage protection 03 trip time |
| UN-G-V01 L-L | 24-422.4 V | 422.4 V | Set grid under-voltage protection 01 value L-L |
| UN-G-V01 L-N | 13.85-243.9 V | 243.9 V | Set grid under-voltage protection 01 value L-L |
| UN-G-V01-T | 2-50 Sec. | 21 S | Grid under-voltage protection 01 trip time |
| UN-G-V02 L-L | 24-240 V | 240 V | Set grid under-voltage protection 02 value L-L |
| UN-G-V02 L-N | 13.85-138.6 V | 138.6 V | Set grid under-voltage protection 02 value L-L |
| UN-G-V02-T | 0.16-21 S | 2 S | Grid under-voltage protection 02 trip time |
| UN-G-V03 L-L | 24-240 V | 240 V | Set grid under-voltage protection 03 value L-L |
| UN-G-V03 L-N | 13.85-138.6 V | 138.6 V | Set grid under-voltage protection 03 value L-L |
| UN-G-V03-T | 0.16-21 S | 2 S | Grid under-voltage protection 03 trip time |
| OV-G-F01 | 61-66 Hz | 61.2 Hz | Set grid over-frequency protection 01 value |
| OV-G-F01-T | 180-1000 S | 300 S | Set grid over-frequency protection 01 trip time |
| OV-G-F02 | 61.8-66 Hz | 62 Hz | Set grid over-frequency protection 02 value |
| OV-G-F02-T | 0.16-1000 S | 0.16 S | Set grid over-frequency protection 02 trip time |
| UN-G-F01 | 50-59 Hz | 58.5 Hz ¹ | Set grid under-frequency protection 01 value |
| UN-G-F01-T | 180-1000 S | 300 S | Set grid uvder-frequency protection 01 trip time |
| UN-G-F02 | 50-57 Hz | 56.5 Hz | Set grid uvder-frequency protection 02 value |
| UN-G-F02-T | 0.16-1000 S | 0.16 S | Set grid uvder-frequency protection 02 trip time |
| Reconnection Voltage L-L | 422.4-456 V 504-508.8 V | 440.2-504 V | Set grid recovery voltage range after grid fault L-L |
| Reconnection Voltage L-N | 243.8-263.3 V 209-293.8 V | 254.1-291 V | Set grid recovery voltage range after grid fault L-N |
| Reconnection Time after Fault | 0-600 S | 300 S | Set reconnection time after a fault is cleared |

10.8 Default Grid Setting for UL-480-18

| Parameter | Range | Default | Description |
|------------------------------|----------------------|---------|---|
| Ramp-up Slew Rate | 0-100% | 100% | Set Ramp-up power slew rate during start-up |
| Reconnect Slew Rate | 0.10-100% | 0.33%V | Set Ramp-up power slew rate during reconnect |
| Volt Watt P3Tau | 0.5-60 S | 10 S | Set power rise time for Volt Watt condition |
| Volt Var Q3Tau | 1-90 S | 5 S | Set reactive power rise time for Volt Var condition |
| OV Frequency derate F-start | 60.017-61 Hz | 60.2Hz | Set OV start frequency for power derate |
| OV Frequency derate droop | 2-5 % | 5 % | Set OV frequency derate droop slope |
| OV Frequency derate response | 0.2-10 S | 5 S | Set OV frequency derate response time |
| UN Frequency derate F-start | 59-59.98 Hz | 59.8 Hz | Set UN start frequency for power derate |
| UN Frequency derate droop | 2-5 % | 5 % | Set UN frequency derate droop slope |
| UN Frequency derate response | 0.2-10 S | 5 S | Set UN frequency derate response time |
| Volt-Watt | Enabled/ Disabled | Enabled | Set Volt - Watt function |
| V1 L-L | 192-288 V | 240 V | Set grid voltage V1 limit for Volt-Watt control |
| P1 | 0-100 % Pn | 100% Pn | Set power P1 for Volt-Watt control |
| V2 L-L | 288-384 V | 336 V | Set grid voltage V2 limit for Volt-Watt control |
| P2 | 0-100 % Pn | 100% Pn | Set power P2 for Volt-Watt control |
| V3 L-L | 504-523.2 V | 508.8 V | Set grid voltage V3 limit for Volt-Watt control |
| P3 | 0-100 % Pn | 100% Pn | Set power P3 for Volt-Watt control |
| V4 L-L | 508.8-528 V | 528 V | Set grid voltage V4 limit for Volt-Watt control |
| P4 | 0-100 % Pn | 20% Pn | Set power P4 for Volt-Watt control |
| Volt-Var | Enabled/ Disabled | Enable | Set Volt-Var function |
| V1 L-L | 369.6-494.4 V | 441.6 V | Set grid voltage V1 limit for Volt-Var control |
| Q1 | 0-60% Sn | +44% Sn | Set reactive power Q1 for Volt-Var control |
| V2 -L-L | 441.6-504 V | 470.4 V | Set grid voltage V2 limit for Volt-Var control |
| Q2 | -60-60% Sn | 0% Sn | Set reactive power Q2 for Volt-Var control |
| V3 L-L | 456-518.4 V | 489.6 V | Set grid voltage V3 limit for Volt-Var control |
| Q3 | -60-60% Sn | 0% Sn | Set reactive power Q3 for Volt-Var control |
| V4 L-L | 465.6-590.4 V | 518.4 V | Set grid voltage V4 limit for Volt-Var control |
| Q4 | -60-0% Sn | -44% Sn | Set reactive power Q4 for Volt-Var control |
| Fixed PF | -0.8 -+0.8 | 1 | Set Fixed Power Factor limit |
| Reactive Power | -60 -60 % | 0% | Set Reactive Power level |

Manufacturer: Ginlong Technologies Co.,Ltd., Ningbo, Zhejiang, P.R.China

US Office: 565 Metro Pl. S. Suite 3214, Dublin OH 43017, USA

Toll-free: 866.438.8408 | Email: sales@ginlong.com | ussales@ginlong.com

Web: www.ginlong.com | www.ginlong.com/us

Please adhere to the actual products in case of any discrepancies in this user manual.

Please record the serial number of your inverter and quote this when you contact us.