


Corrugated PowerClamp, Kit



Product Kit & Components







Part Number	Description
4000630	L-Foot Slotted Set, Mill

Tools overview









Measurment Tape







5/16" Nut Driver


Stringline



Assembly Onto Roof





1



Place the first powerclamps on your marks made on the outside edges of the array. Install the powerclamp using 4 self tapping screws fastened through the pre-punched holes, EPDM gasket, and into the peaks of the corrugated roof panel. Do not over torque screws as you risk stripping the tapped hole in the roof and damaging the sealing

washer. Proper torque is achieved when the screw's EPDM sealing washer sits flush.











1 Attach the L-foot to the top of the Corrugated PowerClamps using the provided M8 serrated flange bolt. Tighten the M8 bolt to 16.5 ft-lbs [22.4 Nm].



- 6
- Repeat step 5 until you have all your L-feet secured and aligned straight on the Corrugated PowerClamps.



CONNECTING STRENGTH



Thank you for choosing a K2 mounting system.

Systems from K2 Systems are quick and easy to install. We hope these instructions have helped. Please contact us with any questions or suggestions for improvement.

Our contact info:

- ▶ k2-systems.com/en-US/contact
- ▶ Telephone: +1.760.301.5300

K2 Systems LLC 2835 La Mirada Drive, Suite A Vista, CA 92081 USA +1.760.301.5300 info@k2-systems.com www.k2-systems.com

Notes



