



DIMENSIONS ARE SHOWN IN INCH AND [MILLIMETERS]

THIS TEMPLATE HAS BEEN PROVIDED TO HELP YOU INSTALL YOUR NEW BLUE SEA SYSTEMS POWER DISTRIBUTION PANEL.

BLUE SEA SYSTEMS
 425 Sequoia Drive Bellingham, WA 98226
 Phone (360)738-8230 Fax (360)734-4195

PANEL CUTOUT DIMENSIONS
 FOR PN 8687 AND PN 8686 PANELS

DATE 5-28-08	SCALE DO NOT SCALE	DOCUMENT NO. 6495	REVISION 001	SHEET 1 OF 1
-----------------	-----------------------	----------------------	-----------------	-----------------